



OfficeSuite

Release 4.1

Administrator Reference Guide

Table of Contents

TABLE OF CONTENTS	I
WELCOME	4
What's New in Release 4.1	4
INTRODUCTION	4
ADMINISTERING THE PHONE SYSTEM	5
Administrator privileges	5
Quick start for the phone system	6
Activate location phones.....	6
Customizing your phone system.....	8
Administering a phone system with other phones	9
Users and locations	9
View users and locations	9
Add a user.....	9
Add a location	11
Modify a user or location.....	13
Disable access for a user or location.....	13
Enable a user or location	13
Edit user on the user's behalf	14
Edit location on the location's behalf	14
Delete a user or location.....	14
View user or location site.....	15
Profiles.....	15
Phone key profiles	15
Permission profiles.....	27
Managing user features	30
Enabling and disabling voice mail.....	31
Reset voice mail PIN	31
Configure permissions	31
Assign a phone key profile.....	32
Assign a phone number.....	32
Login/logout	32
Managing group features.....	33
View call groups.....	35
Assign users to a call group.....	35
Lock members to a call group.....	35
Configure call group call coverage	36
Add a broadcast group	36
Modify a broadcast group	37
Add a call pickup group	38
Modify a call pickup group	38
Add a hunt group	38
Modify a hunt group	39
Change the order of a hunt group member list.....	40

Add a monitor group	40
Modify a monitor group	41
Add a rollover group	41
Modify a rollover group	42
Delete a call group	42
External directory/speed dials.....	43
View the external directory/speed dial list	43
Search external directory/speed dial list.....	43
Add an external directory/speed dial entry	43
Modify an external directory/speed dial entry	44
Delete an external directory/speed dial entry	44
Auto attendant	44
Managing the auto attendant.....	45
Auto attendant menus.....	46
Recording audio prompts and greetings.....	49
Example – Create a custom auto attendant	53
Example – Create a custom auto attendant for voice mail access.....	61
Incoming call routing.....	65
View incoming call routing details.....	65
Configure incoming call routing	66
Enable Emergency Override Routing	67
Disable Emergency Override Routing	67
Example – Configure incoming call routing	68
Business hours	70
View business hours details	70
Configure your business hours details.....	70
Extension ranges.....	71
Configure hold announcement.....	71
Configure account code entry.....	72
Configure zero-out destination.....	72
Site Details.....	73
Phones.....	73
Configure Mitel 5485 paging unit.....	73
Unassign phone.....	74
View phone inventory list.....	74
Print phone inventory list	74
View/modify phone details	74
Delete a phone.....	75
Reset device	75
Assign phone	76
Handling lists	76
Sorting lists	76
Printing lists.....	76

GLOSSARY	77
INDEX	80

Welcome

Congratulations on acquiring your new *Broadspeed OfficeSuite* telephone system!

The *OfficeSuite* system provides all the features that small businesses use, without the up-front cost and ongoing maintenance inherent in owning a traditional system.

OfficeSuite also provides the ability to self-manage your telephone system through an intuitive graphical interface that runs on your web browser.

As an administrator, you can easily add telephone users, set their phone configurations, manage how inbound calls will be routed, and control various other features.

Individual users can customize features on their phones, such as setting up their own call coverage.

What's New in Release 4.1

The following changes between Release 4.0 and Release 4.1 are visible to the administrators:

- **Mitel 5324 IP Phone** - This new phone model is now supported. This is a replacement for the Mitel 5224 IP Phone.
- **Mitel 5304 IP Phone** - This new phone model is now supported.
- **Improved layout on Add/Edit User page** - The layout of the Add User and Edit User page has improved.
- **Call Pickup Groups** - This new type of call group can now be provisioned. See Add a call pickup group on page 38.
- **Per User Hold Announcement** - An announcement to be played for callers on hold can now be provisioned on a per user basis. See Add a user on page 9.

The following changes between Release 4.0 and Release 4.1 are visible to the telephone end users:


- **Mitel 5324 IP Phone** - The telephone users can now use the Mitel 5324 IP phone. This is a replacement for the Mitel 5224 IP Phone but is identical in functionality to the Mitel 5224 IP phone.
- **Mitel 5304 IP Phone** - The telephone users can now use the Mitel 5304 IP phone.
- **Voice Mail control** - The telephone users can now control many of the voice mail settings through the web interface.
- **Call Pickup Groups** - If provisioned by the administrator, telephone users can use call pickup groups.
- **Twinning on/off key** - Telephone users can now program a memory key as a toggle to activate or deactivate their twinning.

Introduction

This document is a reference guide for the administration of the phone system. It describes how to customize your phone system features to suit your business.

The administration of the phone system is completed through a web administration interface that enables you to make changes such as:

- Adding and editing call permission profiles
- Adding and editing phone key profiles
- Configuring an auto attendant
- Configuring incoming call routing
- Adding and editing call groups and their information
- Customizing your phone system

This information is also accessible online in the web administration interface by selecting the Help button at the top or bottom of any page. Context sensitive help is available by selecting the  icon on any page.

Administering the phone system

This section describes how to administer the phone system. To get your phone system working quickly, refer to the section *Quick start for the phone system* on page 6. Then, before making too many changes to the default settings, read *Customizing your phone system* on page 8.

Administrator privileges

Only users with administrator privileges can administer the phone system. An administrator has access to the **Company Settings** menus in the web administration interface, and can therefore create and maintain the following:

- Users and locations
- Profiles
- External directory/speed dial entries
- Call groups
- Auto attendants
- Incoming call routing
- Business details
- Phone inventory

To give a user administrator privileges, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the user.
3. Check the **Administrator Privileges** check box in the **Permissions** section.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

To remove administrator privileges from a user, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the user.
3. Clear the **Administrator Privileges** check box in the **Permissions** section.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Quick start for the phone system

This section describes how to get your phone system working with minimal set up by using default settings.

To quickly set up your phone system using defaults, follow these steps:

1. Add permission profiles. See page 29.
2. Add users. See page 9.
3. Add locations. See page 11.
4. Add an auto attendant. See page 45.
5. Set up incoming call routing. See page 65.
6. Notify users. New users automatically receive their extension and PIN by email if your business has been configured with this option. You may want to also provide them with instructions for getting started.

NOTE: Contact Broadview for information on how your business has been configured for PIN notification. If you are not configured for PIN notification by email, it is your responsibility to provide the users with their extension and the PIN that was displayed when you added them.

1. Activate location phones. See page 6.

Once your phone system is working, you can customize it to suit your company's needs. Refer to *Customizing your phone system* on page 8.

Activate location phones

To activate location phones, log in each telephone that you have added at a location and follow these steps.

The network icon connector is identified by the  symbol.

Mitel IP phones

Activate the Mitel 5340, 5224/5324, and 5304 IP phones with the following procedure:

1. Depending on whether your network is configured with Power Over Ethernet (POE), do the one of the following:
 - **With POE**—Connect the Ethernet cable to the network LAN jack and to the network icon connector of the phone.

- **Without POE**

- a) Connect one end of an Ethernet cable to the network LAN jack and the other to network icon connector of the power supply.
 - b) Connect one end of an Ethernet cable to the phone icon connector on your power supply and the other end to the network icon connector on the phone.
 - c) Plug the phone power pack into a power outlet.
2. If you also need to connect your computer to the LAN, connect an Ethernet cable from your computer's network port to the phone port marked **PC**.
 3. If you have a Mitel 5340, or 5224/5324 IP phone do the following. If you have a Mitel 5304 IP phone, go to step 4:

- a) Wait for the Information Area display to show "Logged Out"
- b) Press the ACTIVATE soft key. The Information Area display will show:

```
_____  
Extension  
_____  
Quit
```

- c) Enter your extension. If you have login/logout privileges, the Information Area display will show:

```
_____  
PIN
```

- d) Enter your PIN.
- e) Press the ENTER soft key. The Information Area display will show:

```
_____  
Extension: xxx  
_____  
Quit
```

where xxx is the extension of your phone.

4. If you have a Mitel 5304 IP phone do the following. If you do not go to the next step:

- a) Wait for the phone to display the following (this may take 30 seconds or more):

```
_____  
Logged Out  
*00
```

- b) To log into your phone, press *00 on the phone keypad. The display will show:

```
_____  
Extension
```

- c) Enter your extension. If you have login/logout privileges, the display will show:

PIN

Enter PIN press #

d) Enter your PIN.

e) Press the # key. The display will show:

Extension: xxx

Quit

where xxx is the extension of your phone.

You have now successfully activated the phone, and can make calls.

Customizing your phone system

If you used the quick start procedures, your phone system is working using default settings. Now you should customize these to suit your company's personality and image. The following guide directs you to the various procedures to help you customize your system:

Do you want call permissions to change depending on the time of day?

This is useful if you want to allow long distance or international calls only during regular business hours. To do this you must setup your business hours and permission profiles appropriately.

- Refer to sections
 - *Business hours* on page 70
 - *Permission profiles* on page 27

Do you want the auto attendant to use different prompts from the defaults provided?

- Refer to section *Auto attendant* on page 44

Do you want the auto attendant to change depending on whether your business is open or closed?

This is normally used to provide callers with the business hours while your business is closed. To do this, you must set up your business hours, add multiple auto attendants, and change your incoming call routing to select a different auto attendant depending on the business hours.

- Refer to sections
 - *Business hours* on page 70
 - *Auto Attendant* on page 44
 - *Incoming call routing* on page 65

Do you want incoming calls to ring at multiple phones?

This will help to ensure that calls do not go unanswered. To do this, you must set up a call group and route incoming calls to that call group.

- Refer to sections:
 - *Managing group features* on page 33
 - *Incoming call routing* on page 65

Do you want an administrator to monitor another user's phone?

This will help administrators to manage a manager's calls. To do this, you must set up a monitor group and program phone keys to Monitor.

- Refer to section *Managing group features* on page 33

Administering a phone system with other phones

The following phones use the Minet protocol and therefore are closely integrated with the product:

- Mitel 5224 IP phone
- Mitel 5304 IP phone
- Mitel 5324 IP phone
- Mitel 5340 IP phone

Users and locations

Users represent the people within your company, while locations represent telephones that are not associated with any single user. For example, a telephone in a conference room or a main reception area is entered into the phone system as a location.

Users have Personal Identification Numbers (PINs), while locations do not. Therefore, locations cannot log in to the web interface (since a PIN is required). Locations are also not represented in the Auto Attendant Company Name Directory.

In order for the users and locations within your company to have full phone service, you must enter them into the system and assign them an extension. You will also maintain other user or location-specific information, such as whether or not a user or location has voice mail and what types of calls can be made from a user or location telephone.

View users and locations

To view a list of users and locations, follow these steps:

1. Select **Users and Locations** in the left menu.
A list of all of the users and locations that have been entered into your system appears.
2. Select the **Last Name** to view detailed information for the user or location.

Add a user

To add a user, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select **Add User** from the **Add** list.

3. In the **User Information** section, enter information in the following fields:

- **First Name:** (optional) The new user's first name. This will be displayed in the Internal Directory on the web and on the phones.
- **Home Phone:** (optional) The new user's home phone number. This information is stored for your reference.
- **Last Name:** (mandatory) The new user's last name. This will be displayed in the Internal Directory on the web and on the phones.
- **Mobile Phone:** (optional) The new user's mobile phone number. This information is stored for your reference.
- **Email:** (optional) The new user's email address. Users will receive their extension and PIN by email if your business has been configured with this option.

4. In the **Phone Information** section, enter information in the following fields:

- **Extension:** (mandatory) The new user's telephone extension. Select an Extension for the new user from the Extension list. The Extension list displays the next five available extensions for users and locations. You can enter a different valid extension by selecting Other from the Extension list and typing the extension of your choice in the text box.

NOTE: You cannot modify the extension once the user has been added.

- **Direct Dial Phone Number:** (optional) Select a number from the list of available phone numbers to dedicate one of your company phone numbers to the new user.
- **Outgoing Caller ID:** (optional) This field defines what external parties will see on their displays when this user calls them. Select **Use Site Number** to use the default number defined by Broadview Networks (shown at the bottom of your Business Details page). Select **Private** to restrict the presentation of the number to the external party. Select any number from your list of company phone numbers to use that number for the outgoing caller ID.
- **Handsfree Answerback:** (optional) Check this box to turn on the new user to program one of their keys to turn on the Handsfree Answerback feature for the user (without using one of their programmable memory keys) (see *Memory key configuration options for profiles* on page 15).
- **User Locked to Phone:** (optional) Check the check box to lock the user to the telephone. This prevents the user from logging out of the phone. See *Login/logout* on page 32. This is recommended for phones that do not have Login/logout capability.
- **Hold Announcement:** (optional) Select an announcement from the pull-down list to be played to callers when the user puts a call on hold.

5. In the **Services** section, check the following boxes (optional):

- **Allow Dialing from Auto Attendant by Extension:** Check this box to allow calls to be transferred to this extension by the auto attendant. (See *Auto attendant* on page 44.)

- **Accessible from Auto Attendant Name Directories:** Check this box to allow calls to be transferred to this extension from the auto attendant's Last Name and First Name directories. (See *Auto attendant* on page 44.)
 - **Enable Twinning:** Check this box to give the new user the Twinning feature
 - **Enable Voice Mail:** Check this box to give the new user voice mail. See *Enabling and disabling voice mail* on page 31 . This will also set the user's call coverage to redirect unanswered calls to voice mail after four rings.
6. In the **Permissions** section, enter information in the following fields (optional):
- **Administrator Privileges:** Check this box to give the new user administrator privileges. See *Administrator privileges* on page 5.
 - **Permission Profile Name:** Select a permission profile from the list. The "Unassigned" profile, which supports emergency and internal call types, is assigned by default.
7. In the **Phone Keys** section, enter information in the following field:
- **Profile Name:** Select a phone key profile from the list. The "System Settings default" profile is assigned by default.
8. Do one of the following:
- Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.
 - Select the **Save and Edit...** button to continue adding or to edit user settings. For example, you can record the auto attendant announcement name by selecting the **Record** button that now appears on the page. See *Record auto attendant name* on page 50.

NOTE: If the new user's PIN is displayed to you, it is your responsibility to communicate this information to the user. The PIN notification method for your company is configured by your system administrator. Contact your system administrator for information on how your business has been configured.

Add a location

To add a location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select **Add Location** from the **Add** list.
3. In the **Location Information** section, enter information in the following fields (mandatory):
 - **Name:** The location name. Displayed in the Internal Directory on the web and on the phones.
4. In the **Phone Information** section, enter information in the following fields:
 - **Extension:** Select an xExtension for the location from the Extension list. The Extension list displays the next five available extensions for users

and locations. You can enter a different valid extension by selecting **Other** from the Extension list and typing the extension of your choice in the text field.

NOTE: You cannot modify the extension once the location has been added.

- **Outgoing Caller ID:**(optional) This field defines what external parties will see on their displays for a call from this location. Select **Use Site Number** to use the default number defined by Broadview Networks (shown at the bottom of your Business Details page). Select **Private** to restrict the presentation of the number to the external party. Select any number from your list of company phone numbers to use that number for the outgoing caller ID.
 - **Location locked to Phone:** Checking this check box prevents users from logging in and out of the location phone.
 - **Handsfree Answerback:** (optional) Check this box to turn on the new user to program one of their keys to turn on the Handsfree Answerback feature for the user (without using one of their programmable memory keys) (see *Memory key configuration options for profiles* on page 15).
 - **Hold Announcement:** (optional) Select an announcement from the pull-down list to be played to callers when the location puts a call on hold.
5. In the **Services** section, enter information in the following fields:
- **Allowing Dialing from Auto Attendant by Extension:**Check this box to allow calls to be transferred to this extension by the auto attendant. (See *Auto attendant* on page 44.)
 - **Accessible from Auto Attendant Name Directories:** Check this box to allow calls to be transferred to this extension from the auto attendant's Last Name and First Name directories. (See *Auto attendant* on page 44.)
 - Check the **Enable Voice Mail** check box to give the location voice mail. This will also set the location's call coverage to redirect unanswered calls to voice mail after four rings.
6. Select a permission profile from the **Profile Name** list in the **Permissions** section. The Unassigned profile is assigned by default.
7. Select a phone key profile from the **Profile Name** list in the **Phone Keys** section. The System Settings default profile is assigned by default.
8. Do one of the following:
- Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.
 - Select the **Save and Edit...** button to continue adding or to edit location settings. For example, you can record the auto attendant announcement name by selecting the **Record** button that now appears on the page. See *Record auto attendant name* on page 50.

NOTE: Users do not require a PIN to log in to a location phone.

Modify a user or location

To modify the information related to an existing user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user or location.
3. Modify information in the fields as required.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Disable access for a user or location

Disable access for a user or location when you want to remove phone system access from users or locations without permanently removing them from the system.

To disable access for a user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select one or more **Users** or **Locations** by checking their corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Disable Selected** button. Disabled users will remain in the list, but the user information is marked with strikethrough lines.

NOTE: Once access is disabled, users are automatically unassigned from their telephones as soon as the phone is in an idle state. They are prevented from making or receiving calls.

A user with access disabled cannot log in to a telephone or the web administration interface.

System administrators cannot disable their own accounts.

Enable a user or location

You can enable disabled users or locations to restore access to their phone system.

To enable a disabled user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select one or more **Users** or **Locations** by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Enable Selected** button. The enabled user or location is displayed in the list without strikethrough lines.

NOTE: Enabled users are not assigned to phones by default but must log in to an available telephone to make and receive calls.

Enabled users can log in to the web administration interface.

Edit user on the user's behalf

Using **Edit User on the User's Behalf**, a system administrator can log in to the web administration as other users and make changes for them.

The following menus are displayed in the left pane when you log in as another user: **My Personal Details**, **My Phone**, **My Call Coverage**, **My Call Groups**, **Internal Directory**, and **External Directory**.

To edit more user settings, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user.
3. Select the **Edit User on the User's Behalf** link at the top of the page.
Logged in as User Name is displayed in the top left corner of the screen to remind you that you are logged in as another user.
4. Once you finish making changes to the user's settings, select the **Save** button on the applicable page.
5. Select **Previous Level** at the top right corner of the page.
You are now logged back into your original session.

Edit location on the location's behalf

Using **Edit Location on the Location's Behalf**, a phone system administrator can log in to the web administration as a location and make changes for the location.

To edit more location settings, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected location.
3. Select the **Edit Location on the Location's Behalf** link at the top of the page. "Logged in as Location Name" is displayed in the top left corner of the screen to remind you that you are logged in as the selected location.
4. Once you finish making changes to the location settings, select the **Save** button on the applicable page.
5. Select **Previous Level** at the top right corner of the page.
You are now logged back into your original session.

Delete a user or location

Deleting users or locations permanently removes them from the system.

To delete a user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select one or more **Users** or **Locations** by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Delete Selected** button.

4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: You cannot delete a user or location if incoming call routing for one of your company phone numbers is configured to use that user or location. To delete the user or location in this case, you must change the incoming call routing configuration for that phone number to use a different extension. Deleting users or locations automatically unassigns them from their telephones – once their phones are idle – and they can no longer make or receive calls. Deleted users cannot log in to telephones or to the web administration interface. System administrators cannot delete their own system accounts. A deleted user or location phone extension can be re-assigned to other users or locations. Deleting a user affects any Phone key profiles, Phone Key Mappings, and Auto Attendants that directly reference the user or location.

View user or location site

If your business has more than one site (office), you can view the user or location site from the users and locations list page.

NOTE: If a user or location is not logged in to a phone, their site is unknown to the system and the text "Logged Out" is displayed.

Profiles

Profiles are used to store preset configurations for phone system features. This enables consistent, quick, and easy deployment of these features to phone system users.

Phone key profiles

This section describes phone key configuration options and how to create and maintain phone key profiles.

Phone key profiles store preset memory key configurations. You can choose different profiles for different users to make using their phones faster and easier to use.

Memory key configuration options for profiles

The following table lists the features that can be programmed on a memory key when creating a phone key profile. Options that require an LED memory key are labeled LED.

Feature	Description	Default Label	Details
----------------	--------------------	----------------------	----------------

Feature	Description	Default Label	Details
Account Code	<p>Assign the Account Code option to a memory key so that an account code can be assigned to a call before or during the call.</p> <p>Note:The Account Code option is not displayed if the Account Codes feature is not enabled for your business.</p>	Account Code	<p>1) Leave the Details box blank if you want users to be prompted for an account code after selecting the Account Code key.</p> <p>2) Type an account code in the Details box if you want the Account Code key to behave like an Account Code Speed Dial key. In this case, when the Account Code key is selected, the account code that you enter is automatically assigned to the call.</p>
Company Speed Dial	<p>Assign the Company Speed Dial option to a memory key to dial one of the phone numbers in your External Directory by pressing the memory key.</p> <p>Note: The Company Speed Dial option is not displayed if you have not configured the system with speed dials.</p>		<p>Selecting the Company Speed Dial option displays a list of the names in your External Directory in the Details field. Select one of the names from this list to enable the Company Speed Dial option.</p>
Directory	<p>Assign the Directory option to a memory key to access the internal directory. This is only appropriate for Mitel 5304 IP phones.</p>	Directory	N/A
Forward to AA (LED)	<p>Assign the Forward to AA (Auto Attendant) option to forward all incoming calls to the Auto Attendant. To turn the Forward to AA feature on and off, select the associated memory key. When the memory key LED is lit, the feature is enabled.</p> <p>Note: The Forward to AA option is not displayed if you have not configured</p>	Forward to **(AA Number)	<p>Selecting the Forward to AA option displays a list of the Auto Attendants in the Details field. Select one of the Auto Attendants from this list to enable the Forward to AA option.</p>

Feature	Description	Default Label	Details
	the system with auto attendants.		
Forward to Co-worker (LED)	Assign the Forward to Co-worker option to forward all incoming calls to a co-worker. To turn the Forward to Co-worker feature on and off, select the associated memory key. When the memory key LED is lit, the feature is enabled.	Forward to, followed by the extension selected.	Selecting the Forward to Co-worker option displays a list of company employees in the system in the Details field. Select a user from this list to enable the Forward to Co-worker option.
Forward to Coverage (LED)	Assign the Forward to Coverage option to forward all incoming calls directly to the call coverage you have set up. To turn the Forward to Coverage feature on and off, select the associated memory key. When the memory key LED is lit, the feature is enabled.	Forward to Coverage	None
Forward to Number (LED)	Assign the Forward to Number option to forward all incoming calls to a user defined phone number. To turn the Forward to Number feature on and off, select the associated memory key. When the memory key LED is lit, the feature is enabled.	Forward to, followed by the number entered in the Details field.	Selecting the Forward to Number option displays a text box in the Details field. Type the phone number that you want to have your calls forwarded to into the text box to enable the Forward to Number option. Note: To forward to an external number, users must have permission to make that external call and Redirect Inbound Call to External Number permission.

Feature	Description	Default Label	Details
Forward to Prompt (LED)	<p>Assign the Forward to Prompt option to forward all incoming calls to a user defined phone number.</p> <p>To turn the Forward to Prompt feature on, select the associated memory key and, using the phone keys, type in the number you would like to have your calls forwarded to. When the memory key LED is lit, the feature is enabled.</p> <p>To turn the Forward to Prompt feature off, select the associated memory key and then the second FWDOFF softkey.</p>	Forward	<p>Note: To forward to an external number, users must have permission to make that external call and Redirect Inbound Call to External Number permission.</p>
Handsfree Answerback (LED)	<p>Assign the Handsfree Answerback option to a memory key so that your phone can automatically answer an intercom call and set up a two-way speech path.</p>	Handsfree Answerback	
Incoming Calls List	<p>Assign the Incoming Calls List option to a memory key to allow you to see the list of recently received incoming calls to your extension. This has the same function as the CALLS softkey.</p>	Incoming Calls List	

Feature	Description	Default Label	Details
Intercom to Co-Worker	Assign the Intercom to Co-Worker option to a memory key to allow you to make a page directly to a co-worker's phone.	Intercom to *** (extension number)	Select a user or location from the Details list to enable the Intercom to Co-Worker option.
Intercom to Prompt	Assign the Intercom to Prompt option to a memory key to allow you to make a page to a co-worker's number that you enter after pressing the key.	Intercom to Prompt	
Join/Leave Group	Assign the Join/Leave Group option to a memory key to join and leave the selected Call Group by selecting the programmed memory key. The memory key LED is lit when you have joined the selected Call Group. Note: The Join/Leave Group option is not displayed if there are no call groups defined.	Name of the selected group	Selecting Join/Leave Group displays available call groups from the Details list. Select a call group from the list to enable the Join/Leave Group option.
Line appearance	Line Appearance keys are required in order to receive incoming calls and to make outgoing calls. Your phone will normally have two or three pre-programmed Line Appearances. The LED on the programmed key indicates the status of the Line Appearance.	Number of the new line in sequence.	

Feature	Description	Default Label	Details
Monitor Call	Assign the Monitor Call option to a memory key to allow call monitoring for an existing monitor group. The user of the phone must be a secondary member of the monitor group.	<i>Monitor Call</i> and extension	Selecting Monitor Call displays available monitor groups in the Details list. Select a monitor group from the list to enable the Monitor Call option.
Monitor Call-Silent	Assign the Monitor Call - Silent option to a memory key to allow call monitoring for an existing monitor group. The user of the phone must be a secondary member of the monitor group.	<i>Monitor Call-Silent</i> and extension	Selecting Monitor Call -Silent displays available monitor groups in the Details list. Select a monitor group from the list to enable the Monitor Call - Silent option.
Monitor Phone	Assign the Monitor Phone option to a memory key to allow call monitoring for an existing monitor group. User of the phone must be a secondary member of the monitor group.	<i>Monitor Phone</i> and extension	Selecting Monitor Phone displays available monitor groups in the Details list. Select a monitor group from the list to enable the Monitor Phone option.
One Touch Speed Dial	Assign the One Touch Speed Dial option to a memory key to allow instant dialling of a pre-defined phone number. The user makes a call by pressing the associated memory key.		Type the number that you want to speed dial in the Details box.
Page	Assign the Page option to a memory key to allow the user to make a page to all of the phones at the site. The page is broadcast through the speaker of each available phone.	Page	

Feature	Description	Default Label	Details
Park/Retrieve	<p>Assign the Park/Retrieve option to put a call on hold at a park location such that it can be retrieved from any other phone at your business that has a memory key configured with the Park/Retrieve option. When you are on an active call, selecting a memory key programmed with the Park/Retrieve feature will park the call. When your phone is idle, selecting a memory key programmed with the Park/Retrieve feature will allow you to retrieve a parked call by entering the park location.</p> <p>Note: If the Park/Retrieve feature is being used by your business, include a memory key configured with Park/Retrieve option in all phone key profiles to ensure that parked calls can be retrieved from any phone.</p>	Park/Retrieve	N/A

Feature	Description	Default Label	Details
Pickup	<p>Assign the Pickup option to a memory key to allow a user to answer an incoming call to any member of the call pickup group.</p> <p>Note: The Pickup option is not displayed if there are no call pickups groups defined.</p>	Pickup	<p>Selecting Pickup displays the available pickup groups in the Details list. Select a pickup group from the list to enable the Pickup option</p>
Redial List / Dial	<p>Assign the Redial List / Dial option to a phone to display the list of recently dialed calls. The key can also be used to Dial a number displayed on the LCD display (Call lists, Redial lists, and Directory displays). This is only appropriate for Mitel 5304 IP phones.</p>	Redial / Dial	N/A

Feature	Description	Default Label	Details
Transfer / Conference	Assign the Transfer / Conference key to a phone to allow transferring and conferencing of calls. Press once to transfer a call and twice to make a three-way call. This is only appropriate for Mitel 5304 IP phones.	Transfer / Conference	N/A
Twinning on/off	Assign the Twinning on/off option to a memory key to allow a user to activate or deactivate their twinning feature.	Twinning	
Unassigned	An Unassigned memory key has no action associated with it.	Unassigned	N/A
Voice Mail	Assign the Voice Mail option to a memory key to allow access to the Voice Mail system. This is only appropriate for Mitel 5304 IP phones.	Voice Mail	N/A

View phone key profiles

To view phone key profiles, follow these steps:

1. Select **Profiles** in the left menu. A list of all call permission and phone key profiles configured for your system appears.
2. Select a profile from the **Name** list to view detailed information for the selected profile.

Default phone key profile

You cannot edit the System Settings default profile. If you do not create and assign a custom phone key profile to a user or location, or if you unassign a user or location from a custom phone key profile, the default phone key profile will be used.

Add a phone key profile

To add a phone key profile, follow these steps:

1. Select **Profiles** in the left menu.
2. Select **Add Phone Key Profile** from the Add list.
3. Type a Profile Name.
4. Select Save.
The profiles list appears.
5. Select the profile name you have just created by checking the box and select **Edit Selected**.
The **Phone Keys Profile Details** page appears.
6. Select the phone model from the Phone Model drop-down list.
7. Select the memory key that you want to program by moving the mouse icon over the button and left-click.
The Program Memory Key Details page appears.
8. Complete the following fields:
 - **Feature:** Select the feature to be programmed.
 - **Locked:** To prevent a user from changing the selected memory key configuration, select this check box.
 - **Label:** Type in a description. If no description is typed, the system default will be applied.
 - **Details:** Select from a drop-down list or type in the required number without any spaces or characters. Not all features require this field.

NOTE: You should lock the Line Appearance configurations in the phone key profile. Line Appearances are required to make and receive phone calls.

9. Select the **Save** button to save the information.
10. Select the **Close Window button** to close the window.
Your phone key profile is updated.

11. Repeat steps 7-10 for each memory key to be programmed.
12. Assign users to the new profile. (optional)

NOTE: To cancel your changes, select the **Close Window** button, instead of the **Save** button in step 9.

Assign a phone key profile to a user or location

To associate users or locations with existing phone key profiles, follow these steps:

1. Select **Profiles** in the left menu.
2. Select the profile name that you want to assign users to by checking the box and select **Edit Selected**.
The **Phone Key Profile Details** page appears.
3. Scroll down the page to the **Available Users List**.
4. Select the user's name or location from the **Available Users** list.
5. Select the right directional arrow button to move the user or location into the **Members of this Profile** list. You can move as many users and locations to the **Members of this Profile** list as you choose. To select multiple users and locations, hold down the **Ctrl** key while selecting each name.
6. To remove members from the profile, select one or more members from the **Members of this Profile** list and then select the left directional arrow button.
7. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Assigning a user or location to a profile applies the profile as soon as the user or location phone is idle. Unassigning a user or location from a profile immediately applies the default phone key profile.

Assigning a phone key profiles to users or locations can affect their existing phone key configurations based on the following rules:

If a key mapping in the new profile is configured as Locked, the changes will overwrite the existing configuration for that key.

If a key mapping in the new profile is not configured as Locked the changes will not overwrite the existing configuration for that key.

Modify a phone key profile

To modify a phone key profile, follow these steps:

1. Select **Profiles** in the left menu.
2. Select the profile name that you want to assign users to by checking the box and select **Edit Selected**.
The **Phone Keys Profile Details** page appears.
3. Modify the **Profile Name** if required.
4. Modify the **Membership List** if required.

NOTE: If you have made changes in steps 3 or 4, select the **Save** button to save your changes before moving to step 5.

5. Select the phone model from the **Phone Model** drop-down list.
6. Select the memory key that you want to program by moving the mouse icon over the button and left-click.
The **Program Memory Key Details** page appears.
7. Complete the following fields:
 - **Feature:** Select the feature to be programmed.
 - **Locked:** To prevent a user from changing the selected memory key configuration, select this check box. You should lock the Line Appearance configurations in the phone key profile. Line Appearances are required to make and receive phone calls.
 - **Label:** Type in a description. If no description is typed the system default will be applied.
 - **Details:** Select from a drop-down list or type in the required number without any spaces or characters. Not all features require this field.
 - **Status:** Only appears with the Forward features. Select Active or Inactive. You will be able to Activate or deactivate the feature by pressing this memory key on the phone once it is programmed.
8. Select the **Save** button to save the information.
9. Select the **Close Window button** to close the window.
Your phone key profile is updated.
10. Repeat steps 6-9 for each memory key to be programmed.
Saving changes to a profile applies them to the members of the profile as soon as the member's phone is idle. Changes to key profiles are applied based on the following rules:
 - If a key mapping is designated Locked, changes will overwrite existing customizations.
 - If a key mapping is not designated Locked, changes will not overwrite existing customizations.

NOTE: You cannot modify the default phone key profile 'System Settings default'.

Delete a phone key profile

To permanently delete a profile from the system, follow these steps:

1. Select **Profiles** in the left menu.
2. Select one or more phone key profiles by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: You cannot delete the default phone key profile 'System Settings default'.

You cannot delete a profile with associated members.

Permission profiles

Permission profiles define permissions for users and locations related to outbound calling. Every user or location is associated with a permission profile, and the ability to place calls depends on the associated profile. This section describes permission types and how to create and maintain permission profiles.

Permission types

The following permission types can be included in a permission profile:

Call Type	Definition
Emergency (911)	Calls to the number used to report an emergency. In North America, dial 9+911. This permission is active for all users at all times.
Internal	Calls to another extension within the same business.
International	International calls to which long-distance charges apply.
Local (external)	Calls within the local calling area of your business. No long-distance charges apply.
Long Distance	Calls outside the local calling area of your business and outside of your region. Long-distance charges apply.
Operator Assisted	Calls in which the operator is involved, typically resulting in long distance charges.
Regional	Calls outside the local calling area of your business and within your region. Long-distance charges apply.
Toll Free (1-800)	Long distance calls to which no charges apply. Typically, these numbers begin with 1-800.
Toll Premium	Calls to a toll number to which charges apply. Typically, these numbers begin with 1-900.
Other	
Redirect Inbound Call to External Number	Allow call coverage, transfer or forward of external calls to an external phone number. Prerequisite: permission to make the external call itself.

Select Long Distance Provider	Include a long distance provider code as part of the dialed digits for a long distance call. Prerequisite: permission for Long Distance and/or International calls.
Select Regional Provider	Include a long distance provider code as part of the dialed digits for long distance calls within your region. Prerequisite: permission for Regional calls.

Permission can be enabled or disabled based on the following business hours categories:

- Open
- Closed
- Lunch
- Special

Broadview Networks defines the dial pattern for each call type.

View permission profiles

To view permission profiles, follow these steps:

1. Select **Profiles** in the left menu. A list of all of the permission and phone key profiles configured for your system appears.
2. Select **Name** to view detailed information for the profile.

Default permission profile

The “Unassigned” profile is the default permission profile. It is preconfigured to allow internal and emergency calls.

The default permission profile is used under the following circumstances:

- To determine what type of calls are allowed from phones where there is no logged-in user.
- If you do not create and assign a custom permission profile for a user or location.
- If you unassign a user or location from a custom permission profile.

Use custom permission profiles for users and locations and the default permission profile to determine what type of calls can be made from phones and locations where there is no logged-in user.

The default permission profile should contain the minimum possible permissions to avoid unauthorized calls that have associated charges.

You can modify the default permission profile to include other call types, but it cannot be deleted.

Add a permission profile

To add a permission profile, follow these steps:

1. Select **Profiles** in the left menu.
2. Select Add Permission Profile from the **Add** list.
3. Type a Profile Name.
4. To allow a call type, check the appropriate **Call Type** check boxes:
 - To allow a call type to occur at any time on any day of the week, select all of the check boxes beside the call type.
 - To allow a call type to occur only during certain business hours, select the check boxes beside the call type that corresponds to the business hours during which the call type is allowed.
5. To disallow a call type, clear all of the check boxes beside the call type.
6. Repeat steps 4 to 5 for each call type.
7. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Emergency and internal call types are enabled by default and cannot be disabled for all business hours in all profiles.
Phones without a logged-in user are assigned to the default “Unassigned” permission profile.

Assign a permission profile to a user or location

To associate users and locations with existing permission profiles, follow these steps:

1. Select **Profiles** in the left menu.
2. Select the **Name** to select a specific permission profile.
3. Select the user or location name in the **Available Users** list.
4. Select the right directional arrow button to move the user or location into the **Members of this Profile** list. You can move as many users and locations to the **Members of this Profile** list as you choose. To select multiple users and locations, hold down the **Ctrl** key while selecting each name.
5. To remove members from the profile, select one or more members from the **Members of this Profile** list and select the left directional arrow button.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Assigning a user or location to a profile applies the new profile as soon as the user or location phone is idle.
Unassigning a user or location from a profile applies the “Unassigned” profile immediately.
Users and locations can only belong to one profile at a time.

Modify a permission profile

To modify a permission profile, follow these steps:

1. Select **Profiles** in the left menu.
2. Select the **Name** to select a specific permission profile.
3. Modify the name of the profile if required.
4. Modify the call permissions by checking or clearing the **Call Type** check boxes as required.
5. Modify the **Members of this Profile** list if required.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: An administrator can modify the default permission profile, Unassigned, with the exception of the **Profile Name** field. Emergency and internal call types are enabled and cannot be modified for all Business hours. Hours of business are configured on the **Business Details** page.

Delete a permission profile

To permanently delete a profile from the system, follow these steps:

1. Select **Profiles** in the left menu.
2. Select one or more profiles by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: You cannot delete the default permission profile "Unassigned". You cannot delete a profile with associated members.

Managing user features

This section provides the procedures required to manage the features available to your users.

For more information, see

- *Enabling and disabling voice mail on page 31*
- *Reset voice mail PIN on page 31*

NOTE: The voice mail PIN is not the same as the PIN the user uses to log into their phone and web interface.

- *Configure permissions on page 31*
- *Assign a phone key profile on page 32*
- *Assign a phone number on page 32*
- *Login/logout on page 32*

Enabling and disabling voice mail

To enable or disable voice mail for a user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** to select the user or location.
3. Choose one of the following:
 - To enable voice mail, check the **Enable Voice Mail** check box in the Services section.
 - To disable voice mail, clear the **Enable Voice Mail** check box in the Services section.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: To enable voice mail for a user or location, there must be voice mail boxes associated with your business that are available for assignment. When you disable voice mail for a user or location, the associated voice mailbox may not become available for assignment until Broadview Networks has deleted the existing messages and recordings.

Reset voice mail PIN

Users are able to reset their own voice mailbox PIN through their web interface. To reset a user's or location's voice mailbox PIN on their behalf, follow these steps:

1. Edit the user on their behalf - see the section Edit the User on the User's Behalf on page 14.
2. Follow the user steps to reset the voice mail. Consult the *Mitel IP Phone Reference Guide*.

NOTE: The voice mail PIN is not the same as the PIN the user uses to log into their phone and web interface. See Reset PIN on page **Error! Bookmark not defined.**

Configure permissions

The permissions profile determines which types of calls users or locations can make from their telephones.

To configure a permission profile for an existing user or location, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user or location.
3. Select a permission profile from the **Permission Profile Name** list in the Permissions section of the user or location **Details** page.
4. Click the **View Profile** button.
The Permission Profile Details page opens.

5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Assign a phone key profile

This section describes how to assign a phone key profile to an existing user or location. Using a phone key profile, you can provide a default configuration for the memory keys on the user or location phone.

To assign a phone key profile, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the user or location.
3. Select a phone key profile from the **Profile Name** list in the **Phone Keys** section of the user or location **Details** page. You can view the details of a phone key profile by first selecting it from the Profile Name list and then selecting the adjacent **View Profile** button.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Assign a phone number

To assign a phone number to a new user, select a phone number from the **Direct Dial Phone Number** list when adding the user. The **Direct Dial Phone Number** list contains a list of all phone numbers available to your company that are unassigned.

To assign a phone number to an existing user, associate the phone number with the user's extension on the Incoming Call Routing page. Refer to *Incoming call routing* on page .

Login/logout

By default, users and locations can log in and log out of phones. To disable the login/logout feature, lock the user or location to the phone.

To lock a user or location to a phone, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user or location.
 - For users, check the **User Locked to Phone** check box in the User Information section.
 - For locations, check the **Location locked to phone** check box in the Location Information section.
3. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

To unlock a user or location from a phone, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user or location.
3. For users, clear the **User Locked to Phone** check box in the User Information section.

4. For locations, clear the **Location locked to phone** check box in the Location Information section.
5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Managing group features

Using call group, incoming calls can be routed to multiple users. Each call group type routes calls to group members differently. Users can join or leave the call groups to which they belong. Certain types of call groups (Broadcast, Hunt, and Rollover) are also associated with call coverage so that calls can be handled even when not answered by a group member. The following table lists the group types available:

Group	Definition	Key
Broadcast group	Incoming calls to a broadcast group are routed to all group members at the same time causing all available members' phone lines to ring simultaneously. The phones stop ringing once the call has been answered or forwarded to call coverage.	Broadcast groups provide an equal opportunity for all group members to answer group calls.
Call pickup group	Incoming calls to any member of a call pickup group ring the member of that group plus provide notification to other members (via a flashing pickup key). Any member of the group can answer the call on behalf of their co-worker by pressing the pickup key. The phone stops ringing once the call is answered or the call is redirected to the member's call coverage setting. Note that the extension used to identify the call pickup group cannot be called.	Call pickup groups allow any member of a group to answer calls for their co-workers.
Hunt group (linear)	Incoming calls to a linear hunt group are routed to each group member in turn, and always start with the first member listed. Each phone rings in turn for a prescribed number of rings. If the call is not answered, it is passed to the next available member's line. This continues until the call is answered or forwarded to call coverage.	Linear hunt groups ring one phone at a time, thus establishing a preference for who will answer a group call.

Group	Definition	Key
<p>Hunt group (circular)</p>	<p>Incoming calls to a circular hunt group are routed to each member of the group in turn, and always start with the member following the last member on the list whose phone rang. Each phone rings in turn for a prescribed number of rings. If the call is not answered, it is passed to the next available member's line. This continues until the call is answered or forwarded to call coverage.</p>	<p>Circular hunt groups share the load of answering a group call because calls do not always route to the first member listed. Phones ring one at a time as the group call is passed from one member to the next on the list.</p>
<p>Monitor groups (Monitor Call)</p>	<p>Incoming calls to the monitor primary group member can be monitored and picked up by the monitor secondary group members if they have a memory key configured to Monitor Call on their phones. Calls to a monitor group will cause the monitor primary and secondary phones to ring until the call is either answered by a group member or forwarded to the call coverage for the monitor primary.</p>	<p>Using monitor call, multiple members can answer incoming calls for another user and can be alerted when that user has available lines. To activate this group once it has been created, assign Monitor Call /Monitor -Silent key mappings for your monitor group's secondary members.</p>
<p>Monitor groups (Monitor Phone)</p>	<p>The primary group member can have their phone monitored for activity rather than their calls. In this instance a secondary group member must have a memory key configured as Monitor Phone. When the primary group member is on a call the secondary members see the LED next to programmed memory key light up.</p>	<p>A secondary member that assigns a Monitor Phone key is able to monitor when the primary member's phone is active as the memory key LED is lit. A memory key that is programmed as a Monitor Phone key can also be used as a speed dial to the monitored user's extension.</p>
<p>Rollover group</p>	<p>Incoming calls to a rollover group are routed to each group member in turn always starting with the first member in the list until an available phone is located. The call rings on this phone until it is answered or forwarded to call coverage.</p>	<p>Calls to a Rollover group will only be presented to the first available group member.</p>

NOTE: When a call to a broadcast or hunt group is ringing, subsequent calls to the same broadcast or hunt group are presented to group members one call at a time when the previous call has been answered.

View call groups

The Call Groups list page displays a list of all call groups in the system. To view call groups, select **Call Groups** in the left menu. A list of all call groups appears.

Assign users to a call group

To associate users with an existing call group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific call group.
3. Select the user's name in the **Available Users** list.
4. Select the right directional arrow button to move the user into the **Members of Call Group** list. You can move as many users to the **Members of Call Group** list as you choose. To select multiple users, hold down the **Ctrl** key while selecting each name.
5. To remove members from the call group, select one or more members from the **Members of this Call Group** list and then select the left directional arrow button.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Users assigned to a broadcast, hunt, or rollover group are logged into the group and can receive calls by default.

Users assigned to a pickup group are logged into the group and can answer calls by default.

When assigning users to a monitor group, the monitor secondaries must configure Monitor Call, Monitor Call Silent, or Monitor Phone memory key mappings in order for the group behavior to take effect.

When assigning users to a hunt group, you must also configure the **After 'x' rings send call to next member** list to specify the number of times each users phone should ring before the call is passed to the next user.

By unassigning a user from a call group, group behavior stops as soon as a call in progress is completed.

Users can belong to multiple groups.

Lock members to a call group

This section describes how to set up a call group in such a way that the members cannot leave it. This ensures that the members are aware of all incoming calls to their call group. This feature applies to broadcast, pickup, hunt and rollover groups only.

To lock members to a call group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific call group.
3. Clear the **Allow Members to Leave Group?** check box.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: By default, call group members are not locked to a call group.

Configure call group call coverage

Call group call coverage determines how a call is handled if none of the call group members answer the call. Call coverage applies only to broadcast, hunt, and rollover groups. The monitor primary call coverage applies to incoming calls to a monitor group. For incoming calls to a member of a call pickup group, the call coverage setting of that member applies. The call coverage options available are: Employee Voice Mail, Auto Attendant, Employee, and Another Phone Number.

To configure call group call coverage, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific broadcast, hunt, or rollover call group.
3. From the **Call Coverage** section, select one of the following call coverage options:
 - **Employee Voice Mail:** This directs the call group to the selected employee's voice mail box.
 - **Auto Attendant:** This directs the call group call to the auto attendant selected from the adjacent list.
 - **Employee:** This directs the call group call to the employee selected from the adjacent list
 - **Another Phone Number:** This directs the call group call to the phone number in the adjacent text box.
4. Define when call coverage will take effect.
 - **Broadcast and rollover groups:** From the **After x rings send this call group's calls to** list, select the number of times you want the phone(s) to ring before call coverage takes effect.
 - **Hunt groups:** From the **After x unanswered phones** list, select the number of times you would like the call to be transferred from one member to another before call coverage takes effect.
5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: No default call coverage is provided when a new broadcast, hunt, or rollover group is added. If call coverage is not configured for a call group, an incoming call rings until the caller hangs up.

Add a broadcast group

To create a new broadcast group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select **Add Broadcast Group** from the **Add** list.
3. Type the broadcast group name in the **Name** field.
4. Select an **Extension** for the broadcast group from the Extension list. The Extension list displays the next five available extensions for Call Groups. You

can enter a different valid extension by selecting **Other** from the Extension list and typing the extension of your choice in the Text field.

5. Select the Call Behavior for the broadcast group. To configure the broadcast group calls to ring on idle group member phones, select **Only ring phones not in use** option.
6. To configure the broadcast group calls to ring on all group member phones even if a group member is already on a call, select the **Ring all phones** option.

NOTE: When the “Ring all phones” option is selected, incoming broadcast group calls are still queued when group member phones are ringing because of a call to the same broadcast group.

7. Add names to the **Members of Call Group** list for the new broadcast group (optional).
8. To lock users to the new call group, clear the **Allow members to leave group?** checkbox (optional).
9. Set up call coverage for the new broadcast group (optional). See *Configure call group call coverage* on page 36.
10. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a broadcast group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage. When a broadcast group is created, it has all call permissions to enable call coverage to an external number.

Modify a broadcast group

To modify an existing broadcast group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific broadcast group.
3. Modify the broadcast group name if required. The Name field cannot be left blank.
4. Select the **Call Behavior** for the broadcast group. To configure the broadcast group calls to ring on idle group member phones, select **Only ring phones not in use** option.
5. To configure the broadcast group calls to ring on all group member phones even if a group member is already on a call, select the **Ring all phones** option.

NOTE: When the “Ring all phones” option is selected, incoming broadcast group calls are still queued when group member phones are ringing because of a call to the same broadcast group.

6. Update the **Members of Call Group** list for the selected broadcast group (optional).
7. Modify whether or not the group members are locked to the selected broadcast group (optional)

8. Modify call coverage for the new broadcast group (optional). See *Configure call group call coverage* on page 36.
9. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a broadcast group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage.

Add a call pickup group

To create a new call pickup group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select **Add Pickup Group** from the Add list.
3. Type the pickup group name in the Name field.
4. Select an **Extension** for the call pickup group from the Extension list. The Extension list displays the next five available extensions for Call Groups. You can enter a different valid extension by selecting **Other** from the Extension list and typing the extension of your choice in the Text field.

NOTE: Note: The Extension is used for group identification purposes only. The extension cannot be dialed.

5. Add names to the Members of Call Group list (by selecting from the Available Users list and then selecting the right arrows) for the new pickup group (optional).
6. If you choose to lock users to the new call group, clear the **Allow Members to Leave Call Group** check box (optional).
7. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Modify a call pickup group

To modify an existing pickup group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific pickup group.
3. Modify the pickup group name if required. The **Name** field cannot be left blank.
4. Update the **Members of Call Group** list for the selected pickup group (optional).
5. If required, modify whether or not the group members are locked to the selected pickup group.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Add a hunt group

To add a new hunt group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select **Add Hunt Group** from the Add list.
3. Type the hunt group name in the **Name** field.
4. Select an **Extension** for the hunt group from the Extension list.
The Extension list displays the next five available extensions for call groups.
You can enter a different valid extension by selecting **Other** from the Extension list and typing the extension of your choice in the Text field.
5. Select the **Hunt Group Type** from the Type list. Circular Hunt Group is the default type.
6. Select the **Call Behavior** for the hunt group.
7. To configure the hunt group calls to ring on idle group member phones, select **Only ring phones not in use** option.
8. To configure the hunt group calls to ring on all group member phones, even if the group member is already on a call, select the **Ring all phones** option.

NOTE: When “Ring all phones” option is selected, incoming hunt group calls are still queued when group member phones are ringing because of a call to the same hunt group. See Managing group features on page 33.

9. Add names to the **Members of Call Group** list for the new hunt group (optional).
10. From the **After 'x' rings send call to next member** list, select how many times you would like a hunt group member’s phone to ring before the call is transferred to the next member (optional).
11. If you choose to lock users to the new call group, clear the **Allow members to leave group?** check box (optional).
12. Set up call coverage for the new hunt group (optional). See *Configure call group call coverage* on page 36.
13. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a hunt group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage. When a hunt group is created, it has all call permissions to enable call coverage to an external number.

Modify a hunt group

To modify an existing hunt group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** corresponding to the hunt group that you want to modify.
3. Modify the hunt group name if required. The **Name** field cannot be left blank.
4. Modify the hunt group type in the **Type** list (optional).
5. Modify the hunt group **Call Behavior** (optional).

6. To configure the hunt group calls to ring on idle group member phones, select **Only ring phones not in use** option.
7. To configure the hunt group calls to ring on all group member phones, even if the group member is already on a call, select the **Ring all phones** option.

NOTE: When Ring all phones option is selected, incoming hunt group calls are still queued when group member phones are ringing because of a call to the same hunt group.

8. Modify the **Members of Call Group** list for the selected hunt group if required.
9. If you choose to lock users to the call group, clear the **Allow members to leave group?** check box (optional).
10. From the **After 'x' rings send call to next member** list, select how many times you would like a hunt group member's phone to ring before the call is transferred to the next member (optional).
11. Modify Call Coverage for the selected hunt group (optional).
12. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a hunt group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage.

Change the order of a hunt group member list

The order in which Hunt Group members appear in the **Members of Call Group** list determines the order in which the phones will ring to address the incoming call.

To change the order of the **Members of Call Group** list, follow these steps.

1. Select **Call Groups** in the left menu.
2. Select the **Name** to choose a specific Hunt Group.
3. Select the **Name** in the Members of Call Group list that you would like to move.
4. Press the **Move Up** button to move the user up in the list, or press the **Move Down** button to move the user down the list.
5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Add a monitor group

To create a new monitor group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select **Add Monitor Group** from the **Add** list.
3. Select the **Primary User** from the list provided. This is the user whose calls will be monitored by other users. A Monitor group takes the name and extension of the Monitor primary.

4. Add names to the **Members of Call Group** list for the new Monitor group (optional). (The Monitor primary is, by default, a member of the Monitor group and cannot be removed.) These are the users that will be monitoring the calls and are referred to as Monitor secondary members.
5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: To enable monitor group behavior, Monitor key mappings must be assigned for your secondary members.

If a monitor group has no members assigned to it, the call is treated as a regular incoming call to the primary user.

Since the monitor group has the same extension as the monitor primary user, there is no change to the way calls are made or received for that user. Their call coverage still applies to their incoming calls. For administrators, continue to use the primary user's extension (as required) when configuring auto attendants or incoming call routing.

Modify a monitor group

To modify the information for an existing monitor group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** corresponding to the monitor group that you want to modify.
3. Modify the **Members of Call Group** list for the selected monitor group (optional).
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a monitor group has no members assigned to it, the call is treated as a regular incoming call to the primary user.

Add a rollover group

To create a new rollover group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select **Add Rollover Group** from the **Add** list.
3. Type the rollover group name in the **Name** field.
4. Select an Extension for the rollover group from the **Extension** list. The Extension list displays the next five available extensions for Call Groups. You can enter a different valid extension by selecting Other from the Extension list and typing the extension of your choice in the Text field.
5. Add names to the **Members of Call Group** list for the new rollover group (optional).
6. If you choose to lock users to the new call group, clear the **Allow members to leave group?** check box (optional).
7. Set up call coverage for the new rollover group (optional). See *Configure call group call coverage* on page 36.

8. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a rollover group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage. When a rollover group is created it has all call permissions to enable call coverage to an external number.

Modify a rollover group

To modify an existing rollover group, follow these steps:

1. Select **Call Groups** in the left menu.
2. Select the **Name** to select a specific rollover group.
3. Modify the rollover group name if required. The Name field cannot be left blank.
4. Update the **Members of Call Group** list for the selected rollover group (optional).
5. Modify whether or not the group members are locked to the selected rollover group (optional).
6. Modify the call coverage for the selected rollover group (optional). See *Configure call group call coverage* on page 36.
7. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If a rollover group has no members assigned to it, or if all members are logged out of their phones, the call goes immediately to call coverage.

Delete a call group

To permanently delete a call group from the system, follow these steps:

1. Select **Call Groups** in the left menu.
2. Choose one or more call groups to delete by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: You cannot delete a Hunt group, Broadcast group, or Rollover group with associated members.

You cannot delete a Hunt group, Broadcast group, or Rollover group if incoming call routing for one of your company phone numbers is configured to use that call group. To delete the call group in this case, you must change the incoming call routing configuration for that phone number to use a different extension. See *Incoming call routing* on page 65.

If you delete a Monitor group, the associated Monitor Call, Monitor Phone and Monitor Silent key mappings will revert to an "Unassigned" key mapping. If you delete a call pickup group, the associated pickup key mapping will

revert to an "Unassigned" key mapping.

External directory/speed dials

Using the external directory feature, you can create and maintain a directory of external names and phone numbers relevant to your company. This list is available from the web administration interface for all users under **Company Directories/External Directory**.

The contact information entered here is also available as an option when configuring memory keys on the phones with the company speed dial feature.

View the external directory/speed dial list

The External Directory/Speed Dial list displays all of the names and phone numbers that you entered in the external directory.

To view the External Directory/Speed Dial list, select **External Directory/Speed Dials** in the left menu. A list of all entries is displayed with the following column headings: Name, Number, and Email. The items located in the Name column are hyperlinks to the corresponding External Directory Entry pages.

Search external directory/speed dial list

To search the External Directory/Speed Dial list, follow these steps:

1. Select **External Directory/Speed Dials** in the left menu.
2. Type a name and/or phone number in the appropriate **Name** or **Number** field.
3. Select the **Search** button. If one or more matches are found, the matches are displayed. If no match is found, the message, "No match found" appears in the information panel.
4. To restore the list to display all entries, select the **Show All** button.

Add an external directory/speed dial entry

To add a new entry to the External Directory/Speed Dial list, follow these steps:

1. Select **External Directory/Speed Dials** in the left menu.
2. Select the **Add Entry** button.
3. Type the contact name you want to assign to the entry in the **Name** field. This can be a person or a company associated with the phone number.
4. Type the phone number you want to assign to the external directory/speed dial entry in the **Phone Number** field.
5. Type an email address for the external directory/speed dial entry contact in the **Email** field (optional).
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.
7. You can choose to map one of the keys on your telephone to dial this number or add it to one of your company phone key profiles.

NOTE: Precede external phone numbers with the appropriate digits as required. For example, you need to include the prefix 9 and 1 + Area Code for long distance numbers.

NOTE: The maximum number of External Directory entries is 100.

Modify an external directory/speed dial entry

To modify the information for an existing external directory/speed dial entry, follow these steps:

1. Select **External Directory/Speed Dials** in the left menu.
2. Select the **Name** in the Name column corresponding to the speed dial that you want to modify.
3. Make the changes of your choice in the Name, Phone Number or Email fields. (Name and Phone Number fields cannot be left blank.)
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Precede external phone numbers with the appropriate digits as required. For example, you need to include the prefix 9 and 1 + Area Code for long distance numbers.

Delete an external directory/speed dial entry

To permanently remove an external directory/speed dial entry, follow these steps:

1. Select **External Directory/Speed Dials** in the left menu.
2. Select one or more entries by checking the corresponding check boxes. To select all entries in the list, check the check box in the heading row.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: Deleting an external directory entry that is being used by a company speed dial phone key mapping will have the following effect: Customized phone key mappings revert to the mapping defined in their phone key profile and phone key mappings in profiles revert to an “Unassigned” mapping.

Auto attendant

The auto attendant can automatically receive and direct your incoming calls without human intervention. The auto attendant is identified by a name and an extension. Perform Auto Attendant manipulations such as deleting based on the auto attendant name and extension.

Menus, prompts, and greetings define how the auto attendant responds when a phone key is pressed. For example, the default choices for the **Auto Attendant** main menu are:

- 1-8 = Transfer to Extension

- 9 = Company Directory
- * = Previous Menu

The auto attendant must have a main menu and can also have additional submenus depending on user configuration.

A set of recorded prompts describing callers' choices is associated with each menu.

Managing the auto attendant

This section describes how to set up and manage the auto attendant.

View auto attendant list

To view the Auto Attendant list, follow these steps:

- Select **Auto Attendant** in the left menu.
A page displays the list of the auto attendants configured for your company. Auto attendants are identified by names and extensions.

View auto attendant details

To view detailed information about a selected auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the auto attendant **Name** to view detailed configuration information. The display contains the following information:
The General Information section contains the auto attendant name and extension information.
A checkmark in the **Time of Day Greetings** check box indicates that time of day greetings are enabled for the selected auto attendant. When times of day greetings are enabled, the system will change the initial greeting to callers, depending on the time of day.
The **Auto Attendant Menu and Menu Options** section displays a link for each auto attendant menu. By default, every auto attendant is created with a main menu. Submenus are created as part of the menu option configuration.
3. Select the **Cancel** button or another option in the left menu to continue.

Add auto attendant

To add a new auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the **Add Auto Attendant** button.
3. Type the auto attendant name in the **Auto Attendant Name** field.
4. Select an Extension for the auto attendant from the **Extension** list. The Extension list displays the next five available extensions for auto attendants. You can enter a different valid extension by selecting **Other** from the Extension list and typing the extension of your choice in the text field provided.
5. Check the **Time of Day Greetings** check box to turn on the Time of Day Greetings (optional). Time of day greeting times are as follows:

- Morning: 12:00 A.M. to 11:59 A.M.
 - Afternoon: 12:00 P.M. to 5:59 P.M.
 - Evening: 6:00 P.M. to 11:59 P.M.
6. Select the **Save** button to save the new auto attendant with the default menu configuration, and default recordings for prompts and greetings.
- The default choices for the Main Menu are as follows:
- 1—8 = Transfer to Extension
 - 9 = Company Directory
 - * = Previous Menu

NOTE: To configure custom menus and choices, select the **Main Menu** link.

Modify an auto attendant

To modify an existing auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the auto attendant **Name**.
3. Make the changes of your choice to Auto Attendant Name or Time of Day Greeting.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Delete an auto attendant

To delete an auto attendant from the system along with its associated menus, choices, prompts, and greetings, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select one or more auto attendants by checking the corresponding check boxes.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

NOTE: You cannot delete an auto attendant if incoming call routing for one of your company phone numbers is configured to use that auto attendant. To delete the auto attendant in this case, you must change the incoming call routing configuration for that phone number to use a different extension. Do not delete an Auto Attendant with a name of Zero-out. This auto attendant is used for a special voice mail feature which Broadview Networks is responsible for configuring.

Auto attendant menus

This section describes how to set up and manage auto attendant menus.

View auto attendant menu details

To view all the menus and choice configurations for a selected auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the **Name** for the auto attendant menu details you want to view.
3. Select the **View Expanded Tree** button at the bottom of the page. An expanded tree view with the **Main** menu, all submenus and associated choices for the selected auto attendant is displayed.

Configure auto attendant menu options

This section describes how to set up or modify the options for auto attendant menus. The menu options define how the system responds when a caller selects a phone key.

Menu options can be assigned to each of the following phone keys: 1—9, 0, *, and #.

NOTE: When configuring an auto attendant menu, consider the extensions that are assigned to the users and locations. Extension numbers that are assigned to users must not share digits with phone key numbers that are used for auto attendant menu options. For example, if you have users assigned to extensions 200 to 210 and you configure your main auto attendant menu to use the 2 key to access a broadcast group, callers to the auto attendant will not be able to reach these users by dialing their extension directly. Dialing a 2 will immediately send the call to the broadcast group.

The choices for each phone key are as follows:

Auto Attendant	Transfers the caller to another specified auto attendant.
Call Group	Transfers the caller to a specified call group.
Extension (dialed)	Transfers the caller to the dialed extension.
First Name Directory	Transfers the caller to the Internal Company Directory, where entries are listed by first name.
Invalid Key	Configures the phone key as unassigned. If a caller presses that phone key on the dial pad, an error message is played.
Last Name Directory	Transfers the caller to the Internal Company Directory, where entries are listed by last name.

Previous Menu	The caller can move back one menu level.
Submenu	Transfers the caller to another menu under the parent menu.
System Disconnect	Disconnects the caller from the system, terminating the call.
User	Transfers the caller to a specified user.
Voicemail Deposit	Prompts the caller for their extension and then transfers them directly to the voice mail box associated with that extension for voice mail deposit.
Voicemail Retrieval	Prompts the caller for their extension and then transfers them to their own voice mail box voice mail retrieval.

To set up or modify auto attendant choices, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the **Name** to select an auto attendant from the list.
3. Select the link in the **Auto Attendant Menu and Menu Options** section of the page for the auto attendant menu that you want to configure.
4. Enter a name for the menu in the **Menu Name** field (optional).
5. Type the introductory prompt text for the menu in the **Introductory Prompt** field (optional). This additional text is saved and can later be used to guide you through recording menu prompts.
6. Select an option from the **Send Caller To** list for each of the phone keys.
7. Type prompt text for each phone key configured in the associated **Wording for Prompt** field (optional). This additional text is saved and can later be used to guide you through recording menu prompts.
8. Select the number of times that you want the auto attendant menu prompts to be repeated from the **Play menu prompt** list.
9. Configure an action for the auto attendant if there is no input from the caller (for example, if a caller was not using a touch tone phone), after prompts have been repeated the configured number of times in the **Play menu prompt** list. There are three options: Call Group, System Disconnect, and User.
10. Select the **Save** button to save the menu options configuration, or select the **Cancel** button to discard your changes.

11. Record a new menu prompt for the affected auto attendant menu. If you do not record a new menu prompt, callers will not know how to navigate the auto attendant. Refer to the *Record audio prompt and greetings* section on page 49 for details.

Add an auto attendant submenu

To set up an auto attendant menu to reference another auto attendant menu, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the **Name** to select an auto attendant from the list.
3. Select the link in the **Auto Attendant Menu** section of the page for the auto attendant menu that you want to create a submenu under.
4. Select the **Submenu** option from the **Send Caller To** list for the phone key that you want the new menu to start from.
5. Type prompt text for the **Submenu** option in the associated Wording for Prompt field (optional). This text is saved and can later be used to guide you through recording menu prompts.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.
7. Configure choices for the new submenu.

Delete an auto attendant submenu

To delete an **Auto Attendant** submenu, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the **Name** to select an auto attendant from the list.
3. Select the link in the **Auto Attendant Menu and Menu Options** section of the page for the auto attendant menu that is the parent to the submenu you want to delete.
4. Change the **Submenu** option to another option in the **Send Caller To** list for the phone key that starts the submenu you are deleting.
5. Type prompt text for the choice that has replaced the **Submenu** option in the associated **Wording for Prompt** field (optional). This additional text is saved and can later be used to guide you through recording menu prompts.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.
7. Re-record your menu prompt to reflect the change in the affected menu.

NOTE: When you delete a submenu, the prompts that have been recorded for the submenu are also deleted.

Recording audio prompts and greetings

This section describes how to record a custom greeting or prompt for the auto attendants you have created.

NOTE: The maximum length of any auto attendant prompt is 3 minutes.

NOTE: Once a prompt has been recorded, it cannot be deleted. To change a prompt, re-record it.

Checking auto attendant name announcement

As a tenant administrator, you can check whether a user has recorded an auto attendant name announcement. If a user does not have a name recorded, callers to an auto attendant in your business who navigate to the auto attendant's name directory will hear "Unknown subscriber" rather than the name of the user or location. If the user does not have an auto attendant name recorded, you can record the name on the user's behalf. See *Record auto attendant name announcement* on page 50.

1. Select **Users and Locations** in the left menu.
A list of all of the users and locations that have been entered into your system appears.
2. Select the **Last Name** to view detailed information for the user or location.
3. Scroll to the **Services** category.
Beside **Auto Attendant Name Announcement**: one of two messages appears:
 - **Recorded**—an auto attendant name is recorded
 - **Not Recorded**—an auto attendant name is not recorded

Record the auto attendant name announcement

The tenant administrator can record the auto attendant name announcement of the user or location. Any enabled user or location phone—such as the phone of the administrator—can be used to record the announcement of the user.

1. Select **Users and Locations** in the left menu.
A list of all of the users and locations that have been entered into your system appears.
2. Select the **Last Name** to view detailed information for the user or location.
3. Select the **Record** button beside **Auto Attendant Name Announcement**.
The Record Name Announcement window opens.
4. Type the extension of the phone on which you want to record the auto attendant name announcement in the **Extension to Call** field. This extension can be any enabled user or location extension, such as your own phone. Auto attendant and call group extensions cannot be used.
5. Select the **Call** button.
The phone of the extension you entered in the **Extension to Call** field will ring a maximum of five times.
6. When your phone rings, lift the handset to answer.
7. Listen to a brief set of audio instructions: "Please record your message after the tone. When you are finished, press # for more options".
8. When you hear the tone, record the user's name into the handset.

9. When you are finished, press the **#** key.
The system plays the following set of options:
 - To listen to the recording, press **1**.
 - To save the recording, press **2**.
 - To re-record, press **3**.
 - To exit without saving changes, press *****.
10. Press **2** to save the name announcement.
11. Replace the handset.
12. Select the **Close** button on the pop-up window.

Record auto attendant time of day greetings

To record custom time-of-day greetings for the auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the auto attendant **Name** to select an auto attendant from the list.
3. Select the **Record** button for the time of day greeting that you want to record.
4. Confirm that the extension displayed matches that of the telephone you will be recording from. Modify the extension if required.
5. Select the **Call** button.
6. When the phone rings, pick up the handset.
7. Listen to the instructions and wait for the tone.
8. Record the greeting into the telephone handset.
9. Press the **#** key when you are finished.
10. Choose from the following options:
 - To replay greeting press **1**
 - To save greeting press **2**
 - To re-record greeting press **3**
 - To exit without saving press *****
11. To record additional greetings, press the appropriate **Record and Call** button and repeat steps 7 through 10.
12. Replace the telephone handset.
13. Select the **Close Window** button to close the Record Prompt window.

Record auto attendant menu prompts

To record custom menu prompts for the auto attendant, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the auto attendant **Name** to select an auto attendant from the list.

3. Select the **Record** link adjacent to the menu or submenu for which you want to record a prompt.
4. Confirm that the extension displayed matches that of the telephone you are recording from. Modify the extension if required.
5. Select the **Call** button.
6. When the phone rings, pick up the handset.
7. Listen to the instructions and wait for the tone.
8. Record the prompt into the telephone handset. You can read the prompt text if you have already entered it.
9. Press the **#** key when you are finished.
10. Choose from the following options:
 - To replay greeting press **1**
 - To save greeting press **2**
 - To re-record greeting press **3**
 - To exit without saving press *****
11. To record additional menu prompts for another menu, press the appropriate **Record** link adjacent to the menu of your choice.
12. Select the **Call** button, and repeat steps 7 through 10.
13. Replace the telephone handset.
14. Select the **Close window** button to close the Record Prompt window.

Record all greetings and menu prompts

To record all of the Auto Attendant menu prompts and time-of-day greetings from a single page while using prompt text, follow these steps:

1. Select **Auto Attendant** in the left menu.
2. Select the auto attendant **Name** to select an auto attendant from the list.
3. Select the **Save and Record All** button at the bottom of the page.
4. Confirm that the extension displayed matches that of the telephone you are recording from. Modify the extension if required.
5. Press the **Record** button beside the prompt or greeting that you want to record.
6. When the phone rings, pick up the handset.
7. Listen to the audio instructions, "Please record your message after the tone. When you are finished, press **#** for more options".
8. When you hear the tone, record the prompt into the handset. Use the prompt text on the Record Prompt page as a reference for what to say.
9. When you are finished, press the **#** key.
10. Choose from the following options:

- To replay the prompt or greeting press **1**
 - To save the prompt or greeting press **2**
 - To re-record the prompt or greeting press **3**
 - To exit without saving press *****
11. For each additional greeting or prompt that you want to record, press the appropriate **Record** button and repeat steps 7 through 10.
 12. Replace the handset.
 13. Select the **Done** button to close the **Record Prompt** page.

Example – Create a custom auto attendant

This topic provides an example of how to create a custom auto attendant. The auto attendant is being created for the fictitious company, Ace Automobiles. Ace Automobiles specializes in the sales and repair of blue, red, and old cars. They have divided their sales and service teams based on a blue, red, or old car specialty.

Prerequisites:

Before setting up the auto attendant for Ace Automobiles, you must do the following:

- Confirm the valid extension ranges for users and call groups.
- Enter all of your employees with telephones as system users.
- Add a Blue Car Sales Call Group, a Red Car Sales Call Group and an Old Car Sales Call Group.

Example: Part A – Create the auto attendant

1. Select **Auto Attendant** in the left menu.
2. Select the **Add Auto Attendant** button.
3. Type the auto attendant name and extension in the General Information section.
4. Check the **Time of Day Greetings** check box in the Time of Day Greeting section to turn on the Time of Day Greetings. Type prompt text in the fields provided for each Time of Day Greeting.
 - Morning greeting
 - Afternoon greeting
 - Evening greeting

Example: Part B – Configure the auto attendant main menu options

Select the **Main Menu** link in the **Auto Attendant Menu** section. This will automatically save the auto attendant that you created in Part A.

Type text in the Introductory Prompt field for the **Main Menu** menu prompt: "Thank you for calling Ace Automobiles."

Define the auto attendant **Main Menu** option for each phone **Key** by selecting a choice from the **Send Caller To** list. At the same time, type prompt text in the **Wording for Prompt** fields that you can use as a reference when recording your prompts.

NOTE: When defining auto attendant phone key options, keep in mind how you have assigned extensions to your users call groups, and auto attendants. One example of how the Ace Automobiles auto attendant main menu could be defined is provided below. The reasons and any limitations for the menu options selected are also provided.

Detailed Description of Main Menu Configuration

Phone key	Menu Option	Result	Wording for Prompt
1	Extension	Transfers caller to dialed extension.	"If you know the extension of the person you are calling, please enter it now."
2	Extension	Transfers caller to dialed extension.	
3	Extension	Transfers caller to dialed extension.	
4	Extension	Transfers caller to dialed extension.	
5	Extension	Transfers caller to dialed extension.	
6	Submenu	Transfers caller to a submenu.	To transfer to our Sales Department, please press 6 .
7	Submenu	Transfers caller to a submenu.	To transfer to our Service Department, please press 7 .
8	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
9	Last Name Directory	Transfers the caller to the internal directory where entries are listed by last name.	To access the Company Directory please press 9 .

Phone key	Menu Option	Result	Wording for Prompt
0	User	Transfers the caller to a specified user. Note: Selecting User displays a list of users in the Details area adjacent to the Send Caller To list. Select the appropriate user from this list.	To speak to an operator, please press 0 .
*	Previous Menu	The caller can jump back one menu level.	To return to the previous menu please press *.
#	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	

Explanation

- Phone keys 1—5 are defined as an Extension option, which allows a caller to type in the extension for any user to reach them.
 - Reason: The valid extension range for users at Ace Automobiles is 100 – 599.
- Phone key 6 is defined as a Submenu option which will be used to access a separate menu for the sales team.
 - Reason: A submenu was required because there would not be enough phone keys to allow direct mapping for all users and call groups on the main menu.
 - Limitation: Selection of phone key 6 for the sales submenu means that call groups cannot be accessed from the main menu by dialing their extension (the valid extension range for call groups is 600 – 699).
- Phone key 7 is defined as a Submenu option which will be used to access a separate menu for the service team.
 - Reason: A submenu was required because there would not be enough phone keys to allow direct mapping for all users and call groups on the main menu.
 - Limitation: Selection of phone key "7" for the service submenu means that if Ace Automobiles had multiple auto attendants, they could not be accessed from the main menu by dialing their extension (the valid extension range for auto attendants: 700 – 899).
- Phone key 9 is defined as a Last Name Directory option to allow a caller to reach employees by typing in the letters of their last name on the phone key pad.

- Reason: Provides a means of reaching employees when the caller does not know their extension.
 - Phone key 0 is defined as a User option to allow a caller to transfer directly to a receptionist.
 - Reason: Provides an easy way to reach a person when the caller does not want to navigate the auto attendant menu.
1. Select the number of times that you want the auto attendant menu prompts to be repeated from the **Play menu prompt** list.
 2. Define the action that should be taken if the caller to the auto attendant does not make a phone key selection after the prompts have been repeated the configured number of times. This could happen, for example, if the caller is calling from a phone that does not have touch-tone capabilities.
 - Select **User** as the action that should be taken if the caller does not select a phone key. A list of users is displayed adjacent to the list. Select the appropriate user from this list.
 - Reason: If the caller does not or is not able to select a phone key, they could be transferred to the operator who can then manually direct their call. If the operator is unavailable, the caller is then transferred to the operator's call coverage.
 3. Select the **Save** button to save the main menu configuration.

Example: Part C – Configure your Auto Attendant Sales menu options

1. Select the first **Submenu** in the Auto Attendant Menu section.
2. Type a submenu name and prompt text for the Submenu prompt.

Menu Name: Sales Menu
Introductory Prompt: You have reached the Ace Automobiles Sales Department.
3. Define the auto attendant menu option for each phone **Key** in the list by choosing from the **Send Caller To** list. At the same time, type prompt text in the **Wording for Prompt** fields that you can use as a reference when recording the prompts.

One example of how the Ace Automobiles auto attendant sales menu could be defined is provided below. In this example, the sales team is reached via call groups that have been set up according to the specialties at Ace Automobiles.

NOTE: Selecting **Call Group** displays a list of call groups in the **Details** area adjacent to the **Send Caller To** list. Select the appropriate **Call Group** from this list.

Detailed Description of Sales Menu Configuration

Phone key	Menu Option	Result	Wording for Prompt
-----------	-------------	--------	--------------------

Phone key	Menu Option	Result	Wording for Prompt
1	Call group	Transfers the caller to a specified call group.	To speak with a blue car sales representative, please press 1 .
2	Call group	Transfers the caller to a specified call group.	To speak with a red car sales representative, please press 2 .
3	Call group	Transfers the caller to a specified call group.	To speak with an old car sales representative, please press 3 .
4	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
5	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
6	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
7	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
0	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
*	Previous Menu	The caller can move back one menu level.	To return to the previous menu please press * .

Phone key	Menu Option	Result	Wording for Prompt
#	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	

1. Select the number of times that you want the auto attendant menu prompts to be repeated from the **Play menu prompt** list.
2. Define the action that should be taken if the caller to the auto attendant does not make a phone key selection. This could happen, for example, if the caller is unsure of what option to select.
 - Select **Call Group** as the action that should be taken if the caller does not select a phone key. A list of call groups is displayed adjacent to the list. Select the appropriate call group from this list.
 - Reason: In this case a call group that contains all members of the call group could be selected. If the caller does not select a phone key there is still an opportunity for one of the members of the sales team to take the call.
3. Select the **Save** button to save the **Sales** menu configuration.

Example: Part D – Configure Auto Attendant Service menu options

1. Select the second **Submenu** in the Auto Attendant Menu section.
2. Type a submenu name and prompt text for the **Submenu** prompt.

Menu Name: Service Menu
Introductory Prompt: You have reached the Ace Automobiles Service Department.
3. Define the auto attendant menu option for each phone **Key** in the list by choosing from the **Send Caller To** list. At the same time, type prompt text in the **Wording for Prompt** fields that you can use as a reference when recording your prompts.

One example of how the Ace Automobiles auto attendant service menu could be defined is provided below. In this example, callers are directed to the service team managers according to the specialties at Ace Automobiles.

NOTE: Selecting **User** will display a list of users in the **Details** area adjacent to the **Send Caller To** list. Select the appropriate user from this list.

Detailed Description of Service Menu Configuration

Phone key	Menu Option	Result	Wording for Prompt
-----------	-------------	--------	--------------------

Phone key	Menu Option	Result	Wording for Prompt
1	User	Transfers caller to a specified user.	To speak with the blue car service manager, please press 1 .
2	User	Transfers caller to a specified user.	To speak with the red car service manager, please press 2 .
3	User	Transfers caller to a specified user.	To speak with the old car service manager, please press 3 .
4	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
5	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
6	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
7	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
8	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	
9	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	

Phone key	Menu Option	Result	Wording for Prompt
0	User	The user can leave the dial pad. action unassigned. If a caller presses that key on the dial pad, an error message is played.	
*	Previous Menu	The caller can move back one menu level.	To return to the previous menu please press *.
#	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	

4. Select the number of times that you want the auto attendant menu prompts to be played from the Play menu prompt list.
5. Define the action that should be taken if the caller to the auto attendant does not make a phone key selection. This could happen, for example, if the caller is unsure of what option to select.
 - Select User as the action that should be taken if the caller does not select a phone key. A list of users is displayed adjacent to the list. Select the appropriate user from this list.
 - Reason: If the caller does not or is not able to select a phone key, they could be transferred to the service manager who can then manually direct their call. If the service manager is unavailable, the caller is then transferred to the service manager's call coverage.
6. Select the **Save** button to save the **Service** menu configuration.

Example: Part E – Record your greetings and prompts

1. Select the **Save and Record All** button at the bottom of the page.
2. Confirm that the extension of the telephone you will be using to record the prompts and greetings matches the extension in the Extension field. Type a different extension if required.
3. Press the **Record** button beside the **Morning Greeting**.
4. When the phone rings, lift the handset.
5. Listen to the audio instructions: “Please record your message after the tone. When you are finished, press # for more options”.
6. When you hear the tone, record the prompt into the handset. Use the prompt text on the Record Prompt page as a reference for what to say.
7. When you are finished, press the # key.

8. Choose from the following options:
 - To replay the prompt or greeting press **1**
 - To save the prompt or greeting press **2**
 - To re-record the prompt or greeting press **3**
 - To exit without saving press *****
9. Press the **Record** button and repeat steps 6 through 10 for the following:
 - Afternoon Greeting
 - Evening Greeting
 - Main Menu prompt
 - Sales Menu prompt
 - Service Menu prompt
10. Replace the handset
11. Select the **Done** button to close the Record Prompt page.

The Ace Automobiles auto attendant is now saved with a custom phone key option configuration and matching custom prompts and greetings recordings.

Example: Part F – Test your auto attendant

Test your set-up by calling the extension that you have assigned to the auto attendant. Listen to the prompts and greetings to ensure that you are satisfied with them, then select each of the phone keys to ensure they respond as you expected.

Example: Part G – Access to your auto attendant

To provide access to your auto attendant from an external phone, you can assign one of your incoming phone numbers to dial directly into the auto attendant. Alternatively, you can choose to have the person whose phone is assigned to your main incoming phone number set call coverage to the auto attendant. See *Incoming call routing* on page 65.

Example – Create a custom auto attendant for voice mail access

This section provides an example of how to create a custom auto attendant that will be used exclusively for voice mail access. This type of auto attendant is useful when the users at your company are frequently out of the office and require easy access to their voice mailbox. Also, by having a separate auto attendant for voicemail access, you do not expose this option to the clients and customers that call in to your main company auto attendant.

Example: Part A – Create the auto attendant

1. Select **Auto Attendant** in the left menu.
2. Select the **Add Auto Attendant** button.
3. Type the auto attendant name and extension in the General Information section.

4. Check the **Time of Day Greetings** check box in the Time of Day Greeting section to turn on the Time of Day Greetings. Type prompt text in the fields provided for each Time of Day Greeting.
 - “Good morning.”
 - “Good afternoon.”
 - “Good evening.”

Example: Part B – Configure the auto attendant main menu options

1. Select the **Main Menu** link in the Auto Attendant Menu section. This will automatically save the auto attendant that you created in Part A.
2. Type text in the **Introductory Prompt** field for the Main Menu menu prompt: “You have reached the automated voice mail access menu.”
3. Define the auto attendant Main Menu menu option for each phone **Key** by selecting a choice from the **Send Caller To** list. At the same time type prompt text in the **Wording for Prompt** fields that you can use as a reference when recording your prompts.

NOTE: Because this auto attendant is being created exclusively for voice mail access, the configuration for phone keys described below has been limited to the VoiceMail Deposit and VoiceMail Retrieval options. All other are keys configured as invalid.

- Phone key 1 is defined as the VoiceMail Deposit option.
- Phone Key 2 is defined as the VoiceMail Retrieval option.
- Phone keys 0, 3-9, * and # are defined as an Invalid Key option.

Detailed Description of Main Menu Configuration

Phone key	Menu Option	Result	Wording for Prompt
1	VoiceMail Deposit	Prompts the caller for their extension and then transfers them to their voicemail box.	“Press 1 for voicemail deposit.”
2	VoiceMail Retrieval	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	“Press 2 for voicemail retrieval.”
3	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.	

4	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
5	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
6	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
7	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
8	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
9	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
0	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
*	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.
#	Invalid Key	The user can leave the dial pad action unassigned. If a caller presses that key on the dial pad, an error message is played.

4. Accept 3 as the default number of times that you want the auto attendant prompt to be repeated from the **Play menu prompt** list.
5. Accept the default action of System Disconnect that is configured for the case when the caller to the auto attendant does not make a selection.
6. Select the **Save** button to save the main menu configuration.

Example: Part C – Record your greetings and prompts

1. Select the **Save and Record All** button at the bottom of the page.
2. Confirm that the extension of the telephone you will be using to record the prompts and greetings matches the extension in the **Extension** field. Type a different extension if required.
3. Press the **Record** button beside the **Morning Greeting**.
4. When the phone rings, lift the handset.
5. Listen to the audio instructions: “Please record your message after the tone. When you are finished, press # for more options”.
6. When you hear the tone, record the prompt into the handset. Use the prompt text on the **Record Prompt** page as a reference for what to say.
7. When you are finished, press the # key.
8. Choose from the following options:
 - To replay the prompt or greeting press **1**
 - To save the prompt or greeting press **2**
 - To re-record the prompt or greeting press **3**
 - To exit without saving press *****.
9. Press the **Record** button and repeat steps 6 through 10 for the following:
 - Afternoon Greeting
 - Evening Greeting
 - Main Menu prompt
10. Replace the handset.
11. Select the **Done** button to close the Record Prompt page.

The voice mail auto attendant is now saved with a custom phone key option configuration and matching custom prompts and greetings recordings.

Example: Part D – Test your auto attendant

Test your set-up by calling the extension that you have assigned to your auto attendant. Listen to the prompts and greetings to ensure that you are satisfied with them, then select each of the phone keys to ensure they respond as you expected.

Example: Part E – Access to your auto attendant

To provide access to your auto attendant from an external phone, assign one of your incoming phone numbers to dial directly into the auto attendant. See *Incoming call routing* on page 65.

Incoming call routing

Incoming call routing is used to configure the call destination for each phone number assigned to your company. You can assign different destinations to the same phone number based on your business hours. The options available for call routing are an auto attendant, an employee, a location or a call group.

In addition to business hours, you can define an emergency override destination (which can be an internal or external number). With a single click, you can set the call routing for all of your company phone numbers to route to the emergency override destination(s). You can also individually set your company numbers to route to the emergency override destination. With a single click, you can restore the call routing for all your company phone numbers back to their previous non-override settings.

View incoming call routing details

To view incoming call routing details, select Incoming Call Routing in the left menu. Your company phone numbers are listed in the Phone Number column.

For the Time of Day routing (Open, Closed, Lunch and Special), the destination for each phone number within your company is displayed as a telephone extension adjacent to the phone number. Call destination can be one of your company auto attendants, users, locations, or call groups.

For the Override routing, the telephone number (as it would be dialed from the default site of your company) to which calls are routed in the Emergency Override state is displayed.

Incoming call routing example

Phone Number	Open	Closed	Lunch	Special	Override
6134356785	120	700	700	700	96135551234
6134356786	135	135	135	135	96135550987

The company in this example can be reached by dialing 6134356785 and 6134356786. The company administrator has configured incoming call routing for those phone numbers as follows:

- 6134356786 is dedicated to a single user. In an emergency override situation, the number will route to 96135551234. This was accomplished by routing this phone number to the user's extension (135) during all business hours, and routing the phone number to 96135551234 for the emergency override situation.

- 6134356785 is configured so that it can be handled by an operator during regular business hours, the company auto attendant during off-hours, and 96135550987 in an emergency override situation. This was accomplished by routing this phone number to the operator's extension (120) during "Open" business hours, to the auto attendant extension (700) during "Closed", "Lunch" and "Special" business hours, and to 96135550987 for the emergency override situation.

If routing has not been set up for a particular business hours category, the routing information is blank.

If no routing destinations have been set up for a phone number, then the number will be enclosed in square brackets "[]".

Configure incoming call routing

Incoming call routing is used to identify a destination for your company phone numbers. If you do not configure incoming call routing for a phone number, the number can still be dialed but cannot be answered. The caller will hear ringing until they choose to end the call.

To configure incoming call routing for a phone number, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the phone number to be configured.
3. In the General Information section, fill in the **Name** to describe the phone number (for example, "Main Number").
4. If you want to enable the **Emergency Override** option, select the checkbox for **Enable Emergency Override Routing**. Deselect the checkbox if you want to disable it.
5. Select a call destination from the following options:
 - Select the **Not Assigned** option if no destination is required.
 - Select the **Auto Attendant** option to direct the call to an auto attendant.
6. Select the auto attendant from the list provided.
7. Select the **Calling Group** option to direct the call to a call group. Select the call group from the list provided.
8. Select the **Employee/Location** option to direct the call to a user or location. Select the user or location from the list provided.
9. Select the **Other** option to direct the call to any other number (including an external number). If you select the **Other** option, fill in the **Number** field and the **Name** field (to describe this route).
10. In the **Time of Day Routing** section, for each of the time of day categories (OPEN hours, CLOSED hours, LUNCH hours, SPECIAL hours), select a call destination from the following options:
 - Select the **Not Assigned** option if no destination is required.
 - Select the **Auto Attendant** option to direct the call to an auto attendant. Select the auto attendant from the list provided.

- Select the **Calling Group** option to direct the call to a call group. Select the call group from the list provided.
 - Select the **Employee/Location** option to direct the call to a user or location. Select the user or location from the list provided.
11. If you want the same routing for all four time of day categories, fill in the OPEN hours call destination, then select the checkbox Use this setting for all time of day routing. The CLOSED, LUNCH and SPECIAL hours routing will automatically be filled in for you.
 12. Select the **Save** button.

NOTE: If the "Not Assigned" option is selected for a phone number, the call is not routed at all. When the number is dialed, the caller will hear ringing until they choose the end the call. When incoming call routing is viewed for this number, the routing information will be blank.

Enable Emergency Override Routing

To enable Emergency Override Routing so that all calls to all of your company phone numbers (that have emergency override destinations configured) will be routed to the configured Emergency Override destination, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the **Enable All Overrides** button.

To enable Emergency Override Routing so that all calls to one of your company phone numbers will be routed to its configured Emergency Override destination, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the phone number for which you want calls to be routed to its configured **Emergency Override** destination
3. In the **Emergency Override** section, select the **Enable Emergency Override Routing** checkbox.

When Emergency Override is enabled, the main Incoming Call Routing page will show all the Time of Day call destinations (Open, Closed, Lunch, Special) as greyed out and the Override destination is displayed in bold.

Disable Emergency Override Routing

To disable Emergency Override Routing so that all call routing returns to the previous configuration, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the **Disable All Overrides** button.

To disable Emergency Override Routing for one of your company phone numbers, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the phone number for which you want to disable the **Emergency Override Routing**.

3. In the **Emergency Override** section, deselect the **Enable Emergency Override Routing** checkbox.

When Emergency Override Routing is disabled, the main Incoming Call Routing page will show all the Time of Day call destinations (Open, Closed, Lunch, Special) in bold and the Override destination greyed out.

Example – Configure incoming call routing

This section provides an example of how to configure incoming call routing. Incoming call routing is being configured for a fictitious company with the following phone numbers: 6132244444, 6132244445, 6132244446.

Requirements

The company has the following requirements for how their phone numbers will be used:

- One phone number will be dedicated to the CEO so that he can be reached directly.
- One phone number will be dedicated to the sales team so that they can be reached directly. All sales team telephones should ring when this phone number is dialed.
- One phone number will be used as the "main" company phone number. They would like this phone number to be directed to an operator during regular business hours and the company auto attendant during off-hours.

Pre-requisites

Before configuring incoming call routing for this company, you must do the following:

- Add the CEO, the operator and all sales team members into the system. See Users and locations.
- Add a call group for the sales team into the system. See Managing group features.
- Add an auto attendant into the system. See Auto attendant.
- Configure the business hour details to match the company's working hours. See Business hours.

Example: Part A – Configure the CEO's phone number

To configure the system so that 6132244444 is the CEO's phone number, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the **Extension** or **Click to Set** associated with 6132244444 under any business hour category.
3. Select the **Employee/Location** option. Select the CEO's name from the list provided.
4. Check the **Use this extension for all hours** check box.
5. Select the **Save** button.

Example: Part B – Configure the sales team phone number

To configure the system so that 6132244445 is the phone number for the sales team, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the **Extension** or **Click to Set** associated with 6132244445 under any business hour category.
3. Select the **Calling Group** option. Select the sales team's call group from the list provided.
4. Check the **Use this extension for all hours** check box.
5. Select the **Save** button.

Example: Part C – Configure the "main" company phone number

To configure the system so that 6132244446 is directed to an operator during regular business hours, follow these steps:

1. Select **Incoming Call Routing** in the left menu.
2. Select the **Extension** or **Click to Set** associated with 6132244446 under the **Open** business hour category.
3. Select the **Employee/Location** option. Select the operator's name from the list provided.
4. Select the **Save** button.

To configure the system so that 6132244446 is directed to an auto attendant during off-hours, follow these steps:

1. Select the **Extension** or **Click to Set** associated with 6132244446 under the **Closed** business hour category.
2. Select the **Auto Attendant** option. Select the auto attendant from the list provided.
3. Select the **Save** button.
4. Select the **Extension** or **Click to Set** associated with 6132244446 under the **Lunch** business hour category.
5. Select the **Auto Attendant** option. Select the auto attendant from the list provided.
6. Select the **Save** button.
7. Select the **Extension** or **Click to Set** associated with 6132244446 under the **Special** business hour category.
8. Select the **Auto Attendant** option. Select the auto attendant from the list provided.
9. Select the **Save** button.

Business hours

Business hour details are used to capture the following information about your company:

- The days that your business is open
- Your regular hours of operation and lunch hour
- Special hours of operation

You can configure permissions for users and incoming call routing to be different for each of the business hour categories.

View business hours details

To view business hours details, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Business Hours – in 24 Hour Time** section.

A grid is used to capture the business hours for your company. The grid has the days of the week (vertical axis) broken down by the hours of service (horizontal axis). The hours of service are divided into three categories, Operating Hours, Lunch, and Special. A checkmark indicates that your company is open for business on a selected day.

NOTE: Time is displayed using the 24-hour format.

The default values for the Operating Hours are: From: 00:00. To: 24:00.

Configure your business hours details

To configure your business hours details, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Business Hours – in 24 Hour Time** section.
3. Check the **Open?** check box beside each day that your company is open for business. Clear or leave the **Open?** check box blank for every day that your business is closed. The **Open?** check box can be cleared without losing the business hours information.
4. Type the **From** and **To** hours of service for each day of the week.

NOTE: If you do not enter information for any of the business hours categories, Closed is the default. The business hours categories take the following priority: Special, Lunch, then Operating Hours. This means that if the configuration indicates that more than one category applies at any particular time, the higher-priority category takes precedence.

- Time is displayed using the 24-hour format. The time 24:00 (24 hours, 00 minutes) refers to 23:59:59.
- **Hour:** Hour of service fields should not exceed 24 hours or be less than 0 hours. Minute fields should not exceed 60 minutes or be less than 0 minutes. The total time, hours + minutes, should not exceed 24 hours or be less than 0 minutes. For example, if the hour field = 24, then the minute field must = 0.

5. Select the **Save** button at the bottom of the page to save your changes, or select the **Cancel** button to discard your changes.

Extension ranges

The phone system has three sets of extension ranges: one for users and locations, one for auto attendants, and one for call groups.

To view extension ranges, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Extension Management** section.

The following fields are displayed:

- **User/Location Min.** Displays the first number for phone extensions.
- **User/Location Max.** Displays the last number available for phone extensions.
- **Call Group Min.** Displays the first number in the range available to use for Call Groups
- **Call Group Max.** Displays the last number in the range available for Call Groups.
- **Auto Attendant Min.** Displays the first number in the range to use for an Auto Attendant.
- **Auto Attendant Max** Displays the last number available to use for an Auto Attendant.

Configure hold announcement

You can select the hold announcement used for callers to your business from a list of hold announcements provided by Broadview Networks. Hold announcements are used for external calls only. Internal callers within a site will not hear the hold announcement.

To configure the hold announcement for your business, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Hold Announcement** section.
3. Select a hold announcement option from the **Hold Announcement** list.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: If you select the System Default option, the default announcement will be played.

Once provisioned for your business, this announcement on hold becomes the default announcement for all the users in your business. You can override this setting on a per user basis by provisioning the user's hold announcement field. See Add a user on page 9.

Configure account code entry

Users can enter account codes against incoming and outgoing calls to associate those calls with a particular client or account. Once entered, account codes are logged in the call records kept Broadview Networks and can be provided to you on request. You can enable and disable the Account Code feature for your business and specify the minimum and maximum valid account code length.

NOTE: To use the Account Code feature, a user must have a memory key programmed with the Account Code feature or be using a phone key profile that has been programmed with the Account Code feature.

Enable account codes

To enable account code entry for your business, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Account Codes** section.
3. Select the **Enabled** option in the **Account Codes** list.
4. Enter the minimum number of digits that an account code can contain in the **Min Account Code Length** field.
5. Enter the maximum number of digits that an account code can contain in the **Max Account Code Length** field.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

NOTE: Minimum and maximum account code length cannot be less than 1 or greater than 20.

Disable account codes

To disable account code entry for your business, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Account Codes** section.
3. Select the **Disabled** option in the **Account Codes** list.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Configure zero-out destination

If Broadview has configured this option on the voice mail system, callers to a voice mailbox would have the option to dial "0" instead of leaving a voice message. When callers dial "0" they are directed to the zero-out destination defined for your company. You can define your company's zero-out destination by creating any of the following with the name "zero-out":

- an auto attendant
- a call group
- special user

For an auto attendant, fill in the **Auto Attendant Name** field as "zero-out". See "Add auto attendant" on page 45.

For a call group (Broadcast, Hunt or Rollover), fill in the **Name** field as "zero-out". See "Add a broadcast group" on page 36, "Add a hunt group" on page 38, "Add a rollover group" on page 41.

For a special user, fill in the **Last Name** field as "zero-out". See "Add a user" on page 9.

Individual users can override the company's zero-out destination. See the *Mitel IP Phone Reference Guide* for details.

Site Details

You can view a list of your company's sites. It is useful to know which site is the default site. This is because any telephone calls originated by a subscriber who is not logged in will be made as if the call had been dialed from the default site.

For example, if a user forwards his or her extension to an external number, then logs out of the phone, the forwarding is still in effect. Any calls to that extension will cause an outgoing call to be made as if it was dialed from the default site. Since your company can have multiple sites that could even be in different cities, then the call might be considered long distance and may or may not require a "1" to be prefixed.

To determine your company's default site, follow these steps:

1. Select **Business Details** in the left menu.
2. Scroll down to the **Site Details** section.
3. The Site Name with a * beside it is your company's default site.

Phones

The system maintains a list of all of the phones that are plugged in and connected to the network at your company.

Configure Mitel 5485 paging unit

To configure a Mitel 5485 paging unit for use in your company, follow these steps:

1. Follow the vendor documentation to physically connect the Mitel 5485 paging unit into your network
2. Add a location in the system. The location extension will be used as the paging unit's extension. See *Add a location* on page 11.
3. Select **Phone Inventory** in the left menu.
4. Select the **Phone Label** corresponding to the MAC address of the 5485 paging unit.
5. Select the location from the **Assigned User/Location** list.
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

The paging unit is now available to receive calls. Whenever anyone uses the paging feature, the paging unit will be one of the devices through which the page is broadcast.

NOTE: If you configure the paging unit to have the Handsfree Answerback feature, then Intercom calls to the paging unit have no time limit. If you do not configure the paging unit to have the Handsfree Answerback feature, then the maximum length of time for an Intercom call is the same as the Paging feature limit.

Unassign phone

To remotely log a user or location out of their telephone, follow these steps:

1. Select **Users and Locations** in the left menu.
2. Select the **Last Name** for the selected user or location.
3. Select the **Unassign** button.
4. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

View phone inventory list

To view all company phones connected to the network, follow these steps:

1. Select **Phone Inventory** in the left menu.
2. The Phone Inventory List page is displayed with the following columns: Phone Label, Model, Assigned User/Location and Site.

Print phone inventory list

To print the Phone Inventory list, follow these steps:

1. Select **Phone Inventory** in the left menu.
2. Select the **Print List** button at the bottom of the Information pane. A new browser window **Phone Inventory List** will open. It has a printable list of the phones and associated information.
3. Select the **Print** button at the bottom of the list.
4. Select the **Close Window** button at the bottom of the list to close the Phone Inventory Print window.

View/modify phone details

Using this feature, the administrator can view and make changes to phones in the company's inventory, including assigning and unassigning users and locations from their phones.

NOTE: When a phone is associated with a user or location, the user or location call permission profile determines which types of calls can be placed from the phone. When a phone is not associated with a user or location, the phone uses the default call permissions profile, "Unassigned" to determine the outbound call permissions.

To view or modify phone details, follow these steps:

1. Select **Phone Inventory** in the left menu.
2. Select the **Phone Label** corresponding to the phone that you want to view/modify.
3. Modify the label if required. The label is used to identify the phone and has a default value corresponding to the MAC address of the phone.
4. Select a user or location from the **Assigned User/Location** list to assign the user or location to the phone (optional).
5. Select **Unassigned** from the **Assigned User/Location** list to unassign the user or location from the phone (optional).
6. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Delete a phone

This section describes how to delete a phone from the system. Once a phone is deleted, it is permanently disconnected from the system. This means that the associated user or location is effectively logged out and is no longer able to receive or make calls.

To delete a phone, follow these steps:

1. Select **Phone Inventory** in the left menu.
2. Select one or more phones by checking the corresponding check boxes. To select all entries in the list, select the check box in the heading row.
3. Select the **Delete Selected** button.
4. Select the **OK** button to confirm the deletion, or select the **Cancel** button to cancel the deletion.

A warning message appears, informing you that the phones selected must be physically disconnected from the network, or they will automatically be re-discovered and re-added to the inventory.

5. Physically disconnect the phone.
6. Select the **OK** button to continue with the deletion once you have physically disconnected the phones. You can select the **Cancel** button to stop the deletion. If you selected the **OK** button, however, the selected phones are deleted and removed from the phone inventory list.

Reset device

Reset device is used to return a phone or other discovered device to a known state when it is out of synch with the phone system.

To reset a phone or device, follow these steps:

1. Select **Phone Inventory** in the left menu.
2. Select the **Phone Label** corresponding to the phone or device that you want to view/modify.
3. Select the **Reset Device** button.

NOTE: User and phone configuration information is maintained when you reset a

device.

Resetting a device may end a call in progress.

Assign phone

It is possible to assign a phone to the user/location's extension. This is needed when the phone does not have Login/logout capability (such as a port on an Foreign exchange Station (FXS) or a Mitel 5485 Paging unit.

For certain types of phones, the phone must be assigned to the user/location's extension since the phone does not have Login/logout capability.

The phone must first be plugged into the network and allowed to initialize.

Once the phone has initialized (the display shows "Logged Out"), you can assign the extension by following these steps:

1. Add a user/location in to the system. The user/location extension will be used for this phone. See *Add users* on page 9.
2. Select **Phone Inventory** in the left menu.
3. Select the **Phone Label** corresponding to the device that you want to configure an extension for. The **Phone Label** will be the MAC address shown on a sticker on the back of the phone.
4. Select the user/location from the **Assigned User/Location** list.
5. Select the **Save** button to save your changes, or select the **Cancel** button to discard your changes.

Handling lists

Much of the information presented to you is provided in lists. This section describes how to sort and print lists.

Sorting lists

To sort a list, choose one of the following options:

- Select any of the table column headings. The rows in the table are sorted in ascending order (alphabetical or numeric, depending on the column heading selected).
- Select the same heading a second time to reverse the order.

Printing lists

To print a list, follow these steps:

1. Select the **Print List** button located at the bottom of the Information pane.
A new browser window will open with a printable version of the list.
2. Sort the list by selecting on any of the column headings.
3. Select the browser window **Print** button or select the **Print** command from the browser menu.
4. Close the **Print Browser** window.

Glossary

3-way call: A feature that connects three phones so that 3 parties can participate in a phone call.

Auto attendant: An automated answering system that performs telephone attendant functions such as answering a call and transferring callers to a specific user without the assistance of a live attendant. The automated answering system provides instructions to the user using voice commands and the user activates these features by pressing keys on their phone.

Broadcast group: A call group where incoming calls are directed to multiple phones. All available phone lines ring simultaneously until the call has been answered or forwarded to the call coverage for the broadcast group. A broadcast group has a member list that defines the phones to which the incoming call should be directed.

Call coverage: Call Coverage defines how calls should be handled when the intended recipient cannot answer them. For example, call coverage can be configured to send calls to voice mail if they are not answered.

Call group: Call groups allow incoming calls to be routed to multiple users. There are three types of call groups; broadcast groups, hunt groups and MONITOR groups. Each call group type routes calls to group members differently. Users can join or leave the call groups to which they belong. Call groups are also associated with call coverage so that calls can be handled even when not answered by a group member.

Call permission profile: Call permission profiles store preset call permission configurations. Different profiles can be saved for different types of users to make configuration of their phone service faster and easier. Administrators assign call permission profiles to users.

Call routing: Call routing defines how incoming calls to a company should be directed. Each phone number is associated with either a user, location, call group or auto attendant.

Feature key: A key on a phone that has been pre-programmed with a specified feature. Feature keys are not user configurable.

Handset: The combination of a microphone and earpiece that is attached to a telephone device, typically through a flexible cord.

Hold: A feature that allows a user to temporarily halt a call in progress. While a call is on hold, the caller will hear silence.

Hunt group (linear): A call group where incoming calls are routed sequentially to each available phone in the hunt group member list starting with the first member on the list. Each phone rings in turn for a prescribed number of rings after which the call is passed to the next available member's line. This continues until the call is answered or forwarded to call coverage. A hunt group has a member list that defines the phones to which the incoming call should be directed.

Hunt group (circular): A call group where incoming calls are routed sequentially to each available phone in the hunt group member list starting with the member who follows the last member on the list whose phone rang. Each phone rings in turn for a prescribed number of rings after which it is passed to the next available member's line. This continues until the call is answered or forwarded to call coverage. A hunt group has a member list that defines the phones to which the incoming call should be directed.

Key pad: The keys on the phone that can be used for dialing.

LCD: The display window on the phone.

LED: An indicator light on a memory or feature key on the phone that indicates the state of the feature associated with the key.

Line appearance: A memory key that has been programmed with the Line Appearance feature. A line appearance key is used to make and receive calls.

Location: Locations represent phones that are not associated with any single user. For example, a telephone in a conference room is entered into the phone system as a location.

Login: The act of establishing a session between a user and the phone or the web administration interface. To login, the user must provide their user id and PIN.

Logout: The act of ending a session between a user and the phone or the web administration interfaces. To logout, the user selects the logout softkey on the phone or the Logout link in the web administration interface.

Memory key: A key on the phone that can be programmed by a user with a selected feature.

Monitor group: A call group where incoming calls to a users' phone can be monitored and answered by another user on another phone. Both phones will ring until the call is either answered by either user or forwarded to the call coverage for the primary user. Monitor groups have primary and secondary group members. The group members must have the appropriate memory key configuration on their phones in order for this feature to be enabled.

Monitor primary: The member of a Monitor group whose phone is being monitored by the other group members. The monitor group inherits the name and extension of the primary member.

Monitor secondary: A member of a Monitor group whose phone can be configured to monitor and answer calls occurring on the primary's phone.

PIN: A numeric code that is required for secure login to a phone or the web interface. This code is specific to a user and should not be shared between users.

Phone key profile: Phone key profiles store preset memory key configurations. Different profiles can be saved for different types of users to make configuration of their phones faster and easier. Phone key profiles can be selected by users and administrators.

Site: A site refers to the physical location of a company office. A company may have more than one site.

Softkey: The three keys on the phone directly below the LCD. Pressing these keys activates the feature that is described directly above the key in the LCD. Softkeys can redefine their function depending on the state of the phone.

Speakerphone: A combination microphone/loudspeaker that is part of a phone and allows a user to have a hands-free conversation.

Speed dial: A pre-programmed phone number in the phone system.

User id: The means by which the phone system identifies a user. This phone system uses a users' extension for the user id.

User: A person who is using the phone system.

Voice mail: A system that can store spoken messages so that the intended recipient can retrieve them at a later date.

Index

3-way call	81	Groups:broadcast, adding	39
Account codes:configuring entry ..	75	Business hours	73
Account codes:disabling	75	Business hours:details	73
Account codes:enabling	75	Business hours:viewing	73
Auto attendant	47	Call Coverage	81
Auto attendant:adding	48	Call groups	81
Auto attendant:adding submenu ..	52	Groups:call, assigning users	37
Auto attendant:auto attendant option	50	Call groups:call coverage, configuring	38
Auto attendant:call group option ..	50	Groups:call, deleting	45
Auto attendant:creating custom, examples	56	Groups:call, locking members	38
Auto attendant:custom auto attendant with voice mail, example	64	Groups:call, viewing	37
Auto attendant:default key configurations	47	Call Type	31, 32
Auto attendant:deleting	49	Incoming call routing:emergency override, routing, disabling	70
Auto attendant:deleting submenu	52	Incoming call routing:emergency override, routing, enabling	70
Auto attendant:extension (dialed) option	50	Enabling and disabling voice mail	33
Auto attendant:first name directory option	50	Extension ranges	74
Auto attendant:invalid key option .	50	Recording:audio prompts;Recording:greetings;Prompts, recording	53
Auto attendant:last name directory option	50	Broadcast groups:description ..	36
Auto attendant:managing	47	Broadcast groups:modify	40
Auto attendant:managing list	48	Hunt groups:description, circular	36
Auto attendant:menu, configuring options	50	Hunt groups:description, linear	36
Auto attendant:menus	49	Groups:managing features	35
Auto attendant:menus, viewing	49	Monitor groups:description, call	37
Auto attendant:modifying	49	Monitor groups:description, phone, linear	37
Auto attendant:previous menu option	50	Rollover groups:description	37
Auto attendant:submenu option ...	51	Hold announcements, configuring	74
Auto attendant:system disconnect option	51	Hunt groups	38
Auto attendant:user option	51	Groups:hunt,adding	41
Auto attendant:viewing details	48	Groups:hunt, modifying	42
Auto attendant:voicemail deposit option	51	Incoming call routing	68
Auto attendant:voicemail retrieval option	51	Incoming call routing:configuring ..	69
		Incoming call routing:configuring, example	71

Incoming call routing:viewing details	68	Permission profiles:redirect inbound call to external	30
Phones:inventory list, printing	77	Permission profiles:regional	29, 30
Phones:inventory list, viewing	77	Permission profiles:toll free (1-800)	30
Line Appearance	82	Permission profiles:toll premium	30
Lists:handling	80	Permission profiles:types	29
Lists:printing	80	Account codes:description	19
Lists:sorting	80	Company Speed Dial	19
Locations:adding	14	Phone key profiles:adding	26
Users:deleting	17	Phone key profiles:assigning.....	34
Users:disabling access	16	Phone key profiles:assigning to a user or location	27
Users:enabling	16	Phone key profiles:default	26
Users:modifying	15	Phone key profiles:deleting	29
Users:overview.....	11	Forward to AA	20
Users:viewing.....	12, 18	Forward to Coverage (LED)	20
Login/logout.....	35	Forward to Co-worker	20
Logout	82	Forward to Number	21
Managing user features	32	Forward to Prompt	21
Auto attendant:menu prompts, recording;Recording:menu prompts	55	Handsfree Answerback	21
5485 paging unit.....	76	Incoming Calls List	22
Phones:activating Mitel phones	7	Intercom to Co-worker	22
Groups:monitor, modifying	44	Intercom to Prompt	22
Auto attendant:name announcement, checking	53	Join/Leave Group	22
Paging unit, configuring.....	76	Line appearance	23
Permission profiles:adding.....	31	Phone key profiles:memory key configuration	18
Permission profiles:call types.....	29	Phone key profiles:modifying	28
Profiles:permission, configuring ...	34	Monitor calls:silent	23
Profiles:permission, default.....	30	Monitor calls	23
Profiles:permission, deleting	32	Monitor phone	23
Permission profiles:Emergency (911)	29	One Touch Speed Dial	23
Permission profiles:external	29	Phone key profiles:options	18
Permission profiles:internal	29	Page	24
Permission profiles:international	29	Park/Retrieve	24
Permission profiles:long distance	29, 30	Phone key profiles:unassigned 25	
Profiles:permission, modifying	32	Phone key profiles:viewing.....	26
Permission profiles:operator assisted	29	Phone numbers, assigning.....	35
		Administrator privileges	6
		Phone system:administering	6

Phones:administering with other phones.....	10	Auto attendant:name announcement, recording;Name announcement:recording.....	53
Phone system:customizing	9	Auto attendant:time of day greeting;Greetings:time of day, recording.....	54
Phones:activating	7	Reset voice mail pin	34
Phones:administering to work with other phones	10	Groups:rollover, adding	44
Phones:deleting	78	Groups:rollover, modifying	44
Phones:details, viewing.....	77	External directory	45
Phones:reset	78	External directory:deleting list	47
Phones:unassigning.....	77	External directory:modifying	46
Phones:unlocking users	35	External directory:searching list ...	46
PIN	33	External directory:viewing	46
PIN:voice mail	34	User guide, introduction	5
Profiles	18, 30, 31, 32	Users and locations	32
Permission profiles.....	29	Users:notifying.....	7
Permission profiles:assigning.....	31	View permission profiles.....	30
Phone key profiles.....	18	Release 4.1, new features.....	4
Quick start for the phone system ...	7		